



MERCURY
GO BOLDLY.™

8M0237504 625 eng



**Operation
Maintenance
and
Installation
Manual**

6 HP EFI FourStroke (209 cc)

© 2026 Mercury Marine



Scan for service and support information

Welcome

You have selected one of the finest marine power packages available. It incorporates numerous design features to ensure operating ease and durability. With proper care and maintenance, you will enjoy using this product for many boating seasons. To ensure maximum performance and carefree use, we ask that you thoroughly read this manual before operating the outboard.

The Operation and Maintenance Manual contains specific instructions for using and maintaining your product. Keep this manual with the product for reference whenever you are on the water. This manual should stay with the outboard engine, if it is sold.

Thank you for purchasing one of our products. We sincerely hope your boating will be pleasant.


Mercury Marine, Fond du Lac, Wisconsin, U.S.A.

Read This Manual Thoroughly

IMPORTANT: Your dealer can provide a demonstration of starting and operating procedures. If you do not understand any portion of this manual, contact your dealer.

Safety Alerts

Throughout this publication and on your power package, safety alerts labeled

WARNING and CAUTION (accompanied by the symbol ) , are used to alert you to special instructions concerning a particular service or operation that may be hazardous if performed incorrectly or carelessly. Observe these alerts carefully.

These safety alerts alone cannot eliminate the hazards that they signal. Strict compliance to these special instructions when performing the service, plus common sense operation, are major accident prevention measures.

WARNING

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

Additional Alerts

Additional alerts provide information that requires special attention:

NOTICE

Indicates a situation which, if not avoided, could result in engine or major component failure.

IMPORTANT: Identifies information essential to the successful completion of the task.

NOTE: Indicates information that helps in the understanding of a particular step or action.

California Proposition 65

California Proposition 65



WARNING: This product can expose you to chemicals including gasoline engine exhaust, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

Notice to Users of This Manual

IMPORTANT: The operator (driver) is responsible for the correct and safe operation of the boat, the equipment aboard, and the safety of all occupants aboard. The operator is strongly encouraged to read this Operation and Maintenance Manual to thoroughly understand the operational instructions for the power package and all related accessories before the boat is used.

Descriptions and specifications contained herein were in effect at the time this was approved for distribution. Mercury Marine, whose policies are based on continuous improvement, reserves the right to discontinue models at any time or to change specifications or designs without notice and without incurring obligation.

Warranty Message

The product you have purchased comes with a **Mercury Marine Limited Warranty**. The terms of the warranty are set forth in the Warranty Manual, which can be accessed any time on the Mercury Marine website, at <https://www.mercurymarine.com/us/en/service-and-support/warranty-coverage-and-product-protection/mercury-limited-warranty>. The Warranty Manual contains a description of what is covered, what is not covered, the duration of coverage, how to best obtain warranty coverage, **important disclaimers, limitations, and waivers**, and other related information. Please review this important information.

Mercury Marine products are designed and manufactured to comply with our own high quality standards, applicable industry standards and regulations, and certain emissions regulations. At Mercury Marine every engine is operated and tested before it is boxed for shipment to make sure that the product is ready for use. In addition, certain Mercury Marine products are tested in a controlled and monitored environment, for up to 10 hours of engine run time, in order to verify and make a record of compliance with applicable standards and regulations. All Mercury Marine product, sold as new, receives the applicable limited warranty coverage, whether the engine participated in one of the test programs described above or not.

This manual contains information required for the safe and proper operation, installation, and maintenance of the product. Use of the product not in accordance with any and all instructions for operation and maintenance outlined in this manual will be considered as improper, abnormal, abusive or non-acceptable use of the product and may result in the Mercury Marine Limited Warranty or legal guarantee (if and where applicable) being fully or partly void.

Copyright and Trademark Information

© MERCURY MARINE. All rights reserved. Reproduction in whole or in part without permission is prohibited.

Alpha, Avator, Axius, Bravo One, Bravo Two, Bravo Three, Bravo Four S, Circle M with Waves Logo, GO BOLDLY, K-planes, Mariner, MerCathode, MerCruiser, Mercury, Mercury with Waves Logo, Mercury Marine, Mercury Precision Parts, Mercury Propellers, Mercury Racing, MotorGuide, OptiMax, Pro XS, Quicksilver, SeaCore, Skyhook, SmartCraft, Sport-Jet, Verado, VesselView, Zero Effort, Zeus, #1 On the Water and We're Driven to Win are registered trademarks of Brunswick Corporation. Mercury Product Protection is a registered service mark of Brunswick Corporation. All other marks are the property of their respective owners.

Important Safety Information

Boater's Responsibilities.....	1
Boat Horsepower Capacity.....	1
Exhaust Emissions.....	1
Outboard Remote Control Models	3
Lanyard Stop Switch.....	4
Staying Safe Around the Outboard.....	7
Safe Operating Practices.....	7
Impact with Underwater Hazards.....	12
Safety Instructions for Hand-Tilled Outboards.....	13

General Information

Specifications.....	15
Component Identification.....	15
Recording the Serial Number.....	18
Model Year Production Code.....	19
Selecting Outboard Accessories.....	19

Installation

Mercury Marine Validated Outboard Mounting Hardware.....	21
Fuel System Requirements.....	21
Boat Transom Height Requirement.....	22
Steering Cable Installation.....	22
Installing the Outboard on the Transom.....	23
Steering Link Rod Installation.....	24
Remote Control Connections.....	26
Battery Installation (Electric Start Models).....	32

Transporting

Aquatic Invasive Species (AIS).....	33
Carrying, Storing, and Transporting an Outboard Removed from the Boat.....	34
Trailing a Boat with Installed Outboard.....	35

Fuel and Oil

Fuel Requirements.....	37
Fuel Demand Valve (FDV) Requirement.....	38
Fuel Tank.....	38
Low Permeation Fuel Hose Requirement	40
Engine Oil Recommendations.....	40

Features and Controls

Tiller Handle Features.....	43
Warning System.....	47
Manual Tilt Features and Operation.....	50
Outboard Operating Angle Considerations.....	54
Trim Tab Adjustment.....	55

Operation

Engine Break-in Procedure.....	57
Prestarting Checklist.....	57
Prestarting Instructions.....	57
Starting the Engine - Tiller Handle Models.....	58
Starting the Engine - Remote Control Models.....	61
Emergency Starting.....	63
Gear Shifting	67
Stopping the Engine	68
Operating in Freezing Temperatures.....	68
Operating in Saltwater or Polluted Water.....	68
Operating Outboard as an Auxiliary Engine.....	69

Maintenance

EPA Emissions Regulations.....	71
Cleaning Care Recommendations.....	72
Top Cowl Removal and Installation.....	74
Inspection and Maintenance Schedule.....	74
Maintenance Schedule Decals.....	76
Battery Inspection	77
Flushing the Cooling System.....	77
Corrosion Control Anode.....	78
Engine Oil.....	78
Fuel System.....	81
Gearcase Lubrication.....	82
Lubrication Points	83
Propeller Replacement	86
Spark Plug Inspection and Replacement.....	88
Timing Belt Inspection (Dealer Service Item).....	89

Storage

Storage Preparation.....	91
Protecting the Fuel System.....	91
Protecting External Outboard Components.....	91
Protecting Internal Engine Components.....	92
Gearcase.....	92
Positioning Outboard for Storage.....	92
Battery Storage.....	93

Troubleshooting

Fuse Replacement.....	95
Starter Motor Will Not Crank the Engine (Electric Start Models)	96
Engine Will Not Start.....	96
Engine Runs Erratically.....	97
Performance Loss.....	97
Battery Will Not Hold Charge.....	97
Submerged Outboard.....	98

Owner Service Assistance

Identification Records.....	99
Service Assistance.....	99
Ordering Literature.....	101

Maintenance Log

Maintenance Log.....	103
----------------------	-----

IMPORTANT SAFETY INFORMATION

Boater's Responsibilities

The operator (driver) is at all times responsible for the correct and safe operation of the boat and the safety of its occupants and the general public. Each operator should read and understand this entire manual before operating the outboard.

At least one additional person onboard should be instructed in the basics of starting and operating the outboard and boat handling, in case the driver is unable to operate the boat.

The operator may be subject to local boating license requirements, which may vary according to boating location.

Boat Horsepower Capacity

⚠ WARNING

Exceeding the boat's maximum horsepower rating can cause serious injury or death. Overpowering the boat can affect boat control and flotation characteristics or break the transom. Do not install an engine that exceeds the boat's maximum power rating.

Most boats have a capacity plate to indicate the maximum power and boat load, as determined by the manufacturer and based on federal guidelines and applicable regulations. Never exceed these maximums.

U.S. COAST GUARD CAPACITY	
MAXIMUM HORSEPOWER	XXX
MAXIMUM PERSON CAPACITY (POUNDS)	XXX
MAXIMUM WEIGHT CAPACITY	XXX

26777

For clarification of horsepower or loading restrictions, contact the boat dealer or the boat manufacturer.

Exhaust Emissions

⚠ WARNING

Inhaling engine exhaust gases can result in carbon monoxide poisoning, which can lead to unconsciousness, brain damage, or death. Avoid exposure to carbon monoxide.

Stay clear from exhaust areas when engine is running. Keep the boat well-ventilated while at rest or underway.

IMPORTANT SAFETY INFORMATION

Be Alert to Carbon Monoxide Poisoning

Carbon monoxide (CO) is a deadly gas that is present in the exhaust fumes of all internal combustion engines, including the engines that propel boats and the generators that power boat accessories. By itself, CO is odorless, colorless, and tasteless, but whenever engine exhaust can be tasted or smelled, CO is being inhaled.



Early symptoms of carbon monoxide poisoning—which are similar to the symptoms of seasickness and intoxication—include headache, dizziness, drowsiness, and nausea.

Boats with enclosed cabins should have one or more CO sensors installed.


Stay Clear of Exhaust Areas

Avoid areas of concentrated engine exhaust gases. When engines are running, keep swimmers away from the boat, and do not sit, lie, or stand on swim platforms or boarding ladders. While underway, do not allow anyone to be positioned immediately behind the boat (platform dragging, teak/body surfing). This practice not only poses the risk of extreme physical harm, but also places that person in an area of high engine exhaust concentration.

Good Ventilation

Ventilate the passenger area by opening side curtains or forward hatches.


The following image shows an example of desired air flow through the boat.




IMPORTANT SAFETY INFORMATION

Poor Ventilation

- **Boat in Motion:** Under certain running or wind conditions, permanently enclosed or canvas enclosed cabins or cockpits with insufficient ventilation may draw in carbon monoxide. The following shows examples of poor ventilation while the boat is moving.



- a -** Operating the boat with the trim angle of the bow too high
 - b -** Operating the boat with no forward hatches open
- **Stationary Boat:** Although the occurrence is rare, on a calm day, persons in an open area of a stationary boat that contains, or is near, a running engine may be exposed to a hazardous level of carbon monoxide. The following shows examples of poor ventilation while the boat is stationary.



- a -** Operating the engine when the boat is moored in a confined space
 - b -** Mooring close to another boat that has its engine operating

Outboard Remote Control Models

⚠ WARNING

Starting the engine with the drive in gear can cause serious injury or death. Never operate a boat that does not have a neutral-safety-protection device.

IMPORTANT SAFETY INFORMATION

The outboard's remote control must be equipped with a start-in-neutral-only protection device. The device prevents the engine from starting when the shift control is in any position other than neutral.




Lanyard Stop Switch

The purpose of a lanyard stop switch is to turn off the engine when the operator moves far enough away from the operator's position (as in accidental ejection from the operator's position) to activate the switch. Tiller handle outboards and some remote control units are equipped with a lanyard stop switch. A lanyard stop switch can be installed as an accessory - generally on the dashboard or side adjacent to the operator's position.

A decal near the lanyard stop switch provides a visual reminder for the operator to attach the lanyard to their personal flotation device (PFD) or wrist.

IMPORTANT: Do not add length to the lanyard cord beyond the original length. Any length extension of the original lanyard cord can result in propeller strike injuries including death, if the operator falls overboard.

The lanyard cord is usually 122–152 cm (4–5 feet) in length when stretched out, with an element on one end that inserts into the switch and a clip on the other end that attaches to the operator's PFD or wrist. The lanyard cord is coiled to prevent entanglement with nearby objects. The cord's extended length minimizes accidental activation should the operator choose to move around in an area close to the normal operator's position. If a shorter lanyard is desired, wrap the lanyard around the operator's wrist or leg, or tie a knot in the lanyard.




Lanyard stop switch and cord examples

- a** - Button style lanyard switch
- b** - Toggle style lanyard switch

IMPORTANT SAFETY INFORMATION

Lanyard Wrist Strap

A wrist strap makes it convenient to attach the lanyard to the operator's wrist. The strap encircles the operator's wrist, and the lanyard clip attaches to the strap, as shown. Adjust the diameter of the strap so that it cannot slip off the wrist during use.



- a** - Wrist strap
- b** - Lanyard clip

The wrist strap is standard equipment for all tiller handle outboard models. It is recommended optional equipment for all other models. The wrist strap is available in both Mercury Marine and Quicksilver branding.



79705

Lanyard Stop Switch and Safe Operation

⚠ WARNING

If the operator falls out of the boat, stop the engine immediately to reduce the possibility of serious injury or death from being struck by the boat. Always properly connect the operator to the stop switch using a lanyard.

IMPORTANT: Instruct at least one other boat occupant on proper starting and operating procedures, should they be required to operate the boat in an emergency.

Activation of the lanyard stop switch will stop the engine immediately. However, a boat will continue to coast for some distance depending upon the velocity and degree of any turn at shutdown. While the boat is coasting, it can cause injury to anyone in the boat's path as seriously as it would when under power.

IMPORTANT SAFETY INFORMATION

The lanyard stop switch stops the engine whenever the operator moves far enough away from the operator's position to activate the switch. This occurs if:

- The operator accidentally falls overboard, or
- The operator moves within the boat away from the operator's position.

Falling overboard and accidental ejections are more likely to occur in certain types of boats such as:

- Low-sided inflatables
- Bass boats
- High performance boats
- Light, sensitive-handling fishing boats operated by a hand tiller

Falling overboard and accidental ejections are also likely to occur as a result of poor operating practices such as:

- Sitting on the back of the seat or gunwale at planing speeds
- Standing at planing speeds
- Sitting on elevated fishing boat decks
- Riding in forward seating (such as in a bow rider) at planing speeds in rough water
- Operating at planing speeds in shallow or obstacle filled waters
- Releasing a steering wheel or tiller handle that is pulling in one direction
- Drinking alcohol or consuming drugs
- Performing high-speed boat maneuvers

Accidental or unintended activation of the switch during normal operation is also a possibility. This could cause any, or all, of the following potentially hazardous situations:

- Occupants could be thrown forward due to unexpected loss of forward motion - a particular concern for passengers in the front of the boat who could be ejected over the bow and possibly struck by the boat.
- Loss of power and directional control in heavy seas, strong current, or high winds.
- Loss of control when docking.

To avoid accidental switch activation, the operator should always be aware of their position in relation to the lanyard stop switch and should:

- Never move away from the operating position while the boat is in motion.
- Never move away from the operating position while the boat is stationary without first disconnecting the lanyard from their person.

IMPORTANT SAFETY INFORMATION

Keep the Lanyard Stop Switch and Lanyard Cord in Good Operating Condition

Before each use, check to ensure that the lanyard stop switch works properly. Start the engine and stop it by pulling the lanyard cord. If the engine does not stop, have the switch repaired before operating the boat.

Before each use, visually inspect the lanyard cord to ensure it is in good working condition and that there are no breaks, cuts, or wear to the cord. Check that the clips on the ends of the cord are in good condition. Replace any damaged or worn lanyard cords.

Staying Safe Around the Outboard

⚠ CAUTION

Prevent injuries from slips and falls while at or near the back of the boat. Surfaces may be uneven or slippery. Keep clear and avoid using any part of the outboard engine as a stabilizer for balance support or as a handhold, foothold, or ladder.

Even when it is not operating, an outboard engine can present hazards to people in the boat and in the water.

- Always ensure that all passengers stay clear of the engine, whether the boat is in motion or stationary and whether the engine is operating or is shut off.
- Never use the outboard as a seat.
- Never use any portion of the outboard as a step.
- Never climb on any part of the outboard or use any portion of it as a handhold.

Safe Operating Practices

Passenger Safety - Pontoon Boats and Deck Boats

Whenever the boat is in motion, observe the location of all passengers. Do not allow any passengers to stand or use seats other than those designated for traveling faster than idle speed. A sudden reduction in boat speed, such as plunging into a large wave or wake, a sudden throttle reduction, or a sharp change of boat direction, could throw them over the front of the boat. Falling over the front of the boat between the two pontoons will position them to be run over by the outboard.

IMPORTANT SAFETY INFORMATION


Boats with an Open Front Deck

⚠ WARNING

Sitting or standing in an area of the boat not designed for passengers at speeds above idle can cause serious injury or death. Stay back from the front end of deck boats or raised platforms and remain seated while the boat is in motion.

No one should ever be on the deck in front of the fence while the boat is in motion. Keep all passengers behind the front fence or enclosure.


Persons on the front deck could easily be thrown overboard or persons dangling their feet over the front edge could get their legs caught by a wave and pulled into the water.



Boats with Front-Mounted, Raised Pedestal Fishing Seats

Elevated fishing seats are not intended for use when the boat is traveling faster than idle or trolling speed. Sit only in seats designated for traveling at faster speeds.

Any unexpected, sudden reduction in boat speed could result in the elevated passenger falling over the front of the boat.



IMPORTANT SAFETY INFORMATION

Protecting People in the Water

While the Boat is in Operation

People in the water cannot take quick action to avoid a boat heading in their direction.



Approach slowly and exercise extreme caution when boating in areas where people may be in the water.

When a boat is moving and the gear shift is in neutral, there is sufficient force by the water on the propeller to cause the propeller to rotate. This neutral propeller rotation can cause serious injury.

While the Boat is Stationary

⚠ WARNING

A spinning propeller, a moving boat, or any solid device attached to the boat can cause serious injury or death to swimmers. Stop the engine immediately whenever anyone in the water is near the boat.

Shift into neutral and shut down the engine before allowing people in the water near the boat.

Safe Boating Recommendations

To safely enjoy the waterways, boat operators must be familiar with local and all other governmental boating regulations and restrictions. Boaters should also consider the following suggestions.

- **Know and obey all nautical rules and laws of the waterways.**
 - All powerboat operators are advised to complete a boating safety course. In the U.S., the U.S. Coast Guard Auxiliary, the Power Squadron, the Red Cross, and the state or provincial boating law enforcement agency provide courses. For more information, visit the Boat U.S. Foundation website at <https://boatus.org/>.
 - Some locations (states, territories, etc.) *require* a boating license or certificate. Always confirm licensing and certification requirements prior to boating in a new location.
- **Perform safety checks and required maintenance.** Follow a regular schedule and ensure that all repairs are properly made.

IMPORTANT SAFETY INFORMATION

- **Check onboard safety equipment.** Regulating bodies in most areas *require* specific safety equipment on every powered boat. Even if not required, consider carrying the following on board, and always check the condition before each outing:
 - Approved fire extinguishers
 - Paddle or oar
 - Two-way radio
 - Weather radio
 - Compass and map or chart of the area
 - Signal devices: flashlight, rockets or flares, flag, and whistle or horn
 - Drinking water
 - First aid kit and instructions
 - Waterproof storage containers
 - Anchor and extra anchor line
 - Spare operating equipment, batteries, bulbs, and fuses
 - Manual bilge pump and extra drain plugs
 - Tools necessary for minor repairs
- **Watch for signs of weather change and avoid foul weather and rough-sea boating.**
- **Tell someone of the boating plans, including the expected route and estimated time of return.**
- **Passenger boarding:** Stop the engine whenever passengers are boarding, unloading, or are near the back (stern) of the boat. Shifting the drive unit into neutral is not sufficient.
- **Use personal flotation devices (PFDs).**
 - U.S. federal law *requires* that there be a U.S. Coast Guard-approved life jacket (personal flotation device), correctly sized and readily accessible for every person onboard, plus a type 4 throwable cushion or ring. It is strongly advised that everyone wear a life jacket at all times while in the boat.
 - U.S. federal law *requires* children 13 years of age and younger to wear a U.S. Coast Guard-approved personal flotation device while the boat is underway.
 - Use of personal flotation devices may be *mandatory* in areas outside of the U.S. Always check local laws and regulations before embarking.
 - Inspect the condition of all PFDs prior to embarking.
- **Prepare other boat operators.** Instruct at least one person onboard on the basics of starting and operating the engine and boat handling in case the driver becomes disabled or falls overboard.

IMPORTANT SAFETY INFORMATION

- **Do not overload the boat.** Most boats are rated and certified for maximum load (weight) capacities (refer to the boat's capacity plate). Know the boat's operating and loading limitations. Know if the boat will float if it is full of water. When in doubt, contact a Mercury Marine Authorized Dealer or the boat manufacturer.
- **Ensure that everyone in the boat is properly seated.** Do not allow anyone to sit or ride on any part of the boat that was not intended for such use. This includes:
 - Backs of seats
 - Gunwales
 - Transom
 - Bow
 - Decks
 - Raised fishing seats
 - Any rotating fishing seat

Passengers should not sit or ride anywhere that sudden unexpected acceleration, sudden stopping, unexpected loss of boat control, or sudden boat movement could cause them to be thrown overboard or into the boat. Ensure that all passengers have a proper seat and are in it before any boat movement.

- **Never operate a boat while under the influence of alcohol or drugs. It is the law.** Alcohol or drugs can impair human judgment and greatly reduce the ability to react quickly.
- **Know the boating area and avoid hazardous locations.**
- **Be alert.** The operator of the boat is responsible by law to maintain a proper lookout by sight and hearing. The operator must have an unobstructed view, particularly to the front. No passengers, load, or fishing seats should block the operator's view when the boat is above idle or planing transition speed. Watch out for others, the water, and the wake.
- **Never drive the boat directly behind a water-skier.** A boat traveling at 40 km/h (25 mph) will overtake a fallen skier who is 61 m (200 ft) in front of the boat in five seconds.
- **Observe safe practices for using the boat for skiing, wake-boarding, or similar activity.**
 - A minimum of two persons should be onboard the boat whenever a skier is in the water: one to drive the boat and one to act as a spotter (facing the skier at all times).
 - Always keep a fallen or down skier on the operator's side of the boat while returning to attend to the skier. The operator should always have the down skier in sight and never back up to the skier or anyone in the water.

IMPORTANT SAFETY INFORMATION

- Some U.S. states and Canadian provinces require a "skier down" flag, have restrictions on spotter age, have rearview mirror requirements, and so forth. Know and obey all federal, state (provincial), and local laws and regulations.
- **Report accidents.**
 - In the U.S., boat operators are *required* by law to file a boating accident report with their state boating law enforcement agency when their boat is involved in certain boating accidents. A boating accident must be reported if:
 - i. There is loss of life or probable loss of life.
 - ii. There is personal injury requiring medical treatment beyond first aid.
 - iii. There is damage to boats or other property where the damage value exceeds \$2,000.00 (lower amounts in some states and territories).
 - iv. There is complete loss of the boat.Seek further assistance from local law enforcement.
 - Accident reporting requirements may vary in areas outside the U.S.

Impact with Underwater Hazards

WARNING

Operating a boat or engine with impact damage can result in product damage, serious injury, or death. If the vessel experiences any form of impact, have a Mercury Marine Authorized Dealer inspect and repair the vessel or power package.

This outboard may be equipped with a hydraulic trim and tilt system that also contains a shock absorbing feature. This feature helps the outboard withstand damage in the case of impact with an underwater object at low to moderate speeds. At higher speeds, the force of the impact may exceed the system's ability to absorb the energy of the impact and cause serious product damage.

No impact protection exists while in reverse. Use extreme caution when operating in reverse to avoid striking underwater objects.

Reduce speed and proceed with caution when driving a boat in shallow water areas or in areas where underwater obstacles may exist that could be struck by the outboard or the boat bottom. **The most significant action that can help reduce injury or impact damage from striking a floating or underwater object is to control the boat speed. Under these conditions, boat speed should be kept to the minimum planing speed, typically 24 to 40 km/h (15 to 25 mph).**

IMPORTANT SAFETY INFORMATION

⚠ WARNING

Avoid serious injury or death from all or part of an outboard or drive unit coming into the boat after striking a floating or underwater object. When operating in waters where objects may be at the surface or just under the surface of the water, reduce speed and keep a vigilant lookout.

Examples of objects that can cause engine damage are dredging pipes, bridge supports, wing dams, trees, stumps, and rocks.



Striking a floating or underwater object could result in any number of situations. Some of these situations could yield the following:

- Part of the outboard or the entire outboard could break loose and fly into the boat.
- The boat could move suddenly in a new direction. A sharp change in direction can cause occupants to be thrown out of their seats or out of the boat.
- The boat's speed could rapidly reduce. This will cause occupants to be thrown forward or even out of the boat.
- The outboard or boat could sustain impact damage.

After striking a submerged object, stop the engine as soon as possible and inspect it for any broken or loose parts. If damage is present or suspected, the outboard should be taken to an authorized dealer for a thorough inspection and necessary repair.

The boat should also be checked for any hull fractures, transom fractures, or water leaks. If water leaks are discovered after an impact, immediately activate the bilge pump.

Operating a damaged outboard could cause additional damage to other parts of the outboard or could affect control of the boat. If continued running is necessary, do so at greatly reduced speeds.

Safety Instructions for Hand-Tilted Outboards

No person or cargo should occupy the area directly in front of the outboard while the boat is in motion. If an underwater obstacle is struck, the outboard will tilt up and could seriously injure anyone occupying this area.

IMPORTANT SAFETY INFORMATION

Models with Clamp Screws


⚠ WARNING

Failure to correctly fasten the outboard could result in the outboard propelling off the boat transom resulting in property damage, serious injury, or death. Before operation, the outboard must be correctly installed with the required mounting hardware.

Some outboards come with transom bracket clamp screws. The use of clamp bracket screws alone is insufficient to properly and safely secure the outboard to the transom. Proper installation of the outboard includes bolting the engine to the boat through the transom. Refer to **Outboard Installation** for more complete installation information.

If an obstacle is struck at planing speed and the outboard is not securely fastened to the transom, it is possible the outboard could lift off the transom and land in the boat.

A decal on the swivel bracket reminds the installer of the potential hazard.



52375

GENERAL INFORMATION

Specifications


Parameter		Specification
Rated power		4.4 kW (6 hp)
Number of cylinders		2
Full throttle range		5000–6000 RPM
Idle speed in forward gear		900–1000 RPM
Piston displacement		209.8 cc (12.8 cid)
Spark plug	Recommended model	NGK DCPR6E
	Gap	0.9 mm (0.035 in.)
Gear ratio		2.08:1
Recommended fuel		Refer to Fuel and Oil
Recommended oil		Refer to Fuel and Oil
Engine oil capacity		800 ml (27.0 fl oz)
Gearcase lubricant capacity		320 ml (10.8 fl oz)
Battery rating (electric start models)		465 MCA or 350 CCA
Emission control system		Engine modification (EM)

Component Identification

The following component identification illustrations are intended to represent a cross-selection of available options for the Mercury Marine 6 hp EFI FourStroke. Not all models will have all of the features shown.

GENERAL INFORMATION

Starboard View




- a** - Top cowl
- b** - Tiller handle (refer to **Tiller Handle Features**)
- c** - Throttle only button (tiller handle models)
- d** - Transom angle preset knob (manual tilt models)
- e** - Gear lubricant level plug
- f** - Water inlet
- g** - Gear lubricant fill/drain plug
- h** - Trim tab
- i** - Oil drain plug
- j** - Water pump indicator hole
- k** - Top cowl latch

78089


GENERAL INFORMATION

Front View



Tiller handle model

- a** - Fuel line connector
- b** - Warning light
- c** - Start switch (electric start models)
- d** - Lanyard stop switch
- e** - Battery cables (electric start models)
- f** - Copilot tension adjustment



Remote control model

- a** - Fuel line connector
- b** - Warning light
- c** - Steering bracket
- d** - Carry handle

GENERAL INFORMATION

Port View



- a** - Manual start handle
- b** - Engine flush connector
- c** - Water inlet
- d** - Tilt lock knob (manual tilt models)
- e** - Tiller lock release lever


78093

Recording the Serial Number

Record the serial number and model number for future reference. An **Identification Records** table is available for this purpose, at the back of this manual.


GENERAL INFORMATION

A decal containing serial number and model number is located on the outboard's transom bracket.



Model Year Production Code

The serial number decal lists the year of manufacture as an alpha code. This code can be deciphered into a corresponding number using the following table.



Serial number decal alpha code

Model Year Manufactured Code										
Alpha Production Code	A	B	C	D	E	F	G	H	K	X
Corresponding Number	1	2	3	4	5	6	7	8	9	0

Examples:

- BX = 2020
- HK = 2089
- AG = 2017

Selecting Outboard Accessories

IMPORTANT: Check with an authorized dealer before installing accessories. The misuse of approved accessories or the use of nonapproved accessories can damage the product.

GENERAL INFORMATION

Genuine Mercury Precision or Quicksilver accessories have been specifically designed and tested for each Mercury Marine outboard. These accessories are available from Mercury Marine dealers.

Some accessories not manufactured or sold by Mercury Marine are not designed to be safely used with this outboard or outboard operating system and may void the limited warranty. Read the installation, operation and maintenance manuals for all selected accessories.

INSTALLATION

Mercury Marine Validated Outboard Mounting Hardware

IMPORTANT: Do not mount any accessory—such as tow sport bars or boarding ladders—onto the boat using the mounting hardware included with the outboard. Installing other products onto the boat by using the outboard mounting hardware will compromise the ability of that hardware to properly and safely secure the outboard to the transom.

Improper installation of the outboard can cause performance and reliability issues that can lead to safety concerns. Follow all instructions relating to outboard installation.

Mercury Marine provides validated fasteners and installation instructions, including torque specifications, with all outboards so they can be properly secured to boat transoms.

Outboards that require validated mounting hardware will have the following decal on the transom clamp.



51965

Fuel System Requirements


When installing the boat's fuel system, refer to **Fuel and Oil** for fuel system requirements:

- Low Permeation Fuel Hose Requirement
- Fuel Demand Valve (FDV) Requirement
- EPA Pressurized Portable Fuel Tank Requirements
- Mercury Marine's Pressurized Portable Fuel Tank

INSTALLATION


Boat Transom Height Requirement

Measure the transom height of the boat. The anti-ventilation plate should be 25–50 mm (1–2 in.) below the bottom of the boat.




Steering Cable Installation

1. Lubricate the entire cable end with Mercury Precision or Quicksilver 2-4-C with PTFE.




Description	Where Used	Part No.
2-4-C with PTFE	Steering cable end	92-802859A 1

2. Insert the steering cable into the tilt tube.



3. Tighten the steering cable nut to the specified torque.



Description	Nm	lb-in.	lb-ft
Steering cable nut	47.5	–	35


INSTALLATION

Installing the Outboard on the Transom

⚠ WARNING


Failure to correctly fasten the outboard could result in the outboard propelling off the boat transom resulting in property damage, serious injury, or death. Before operation, the outboard must be correctly installed with the required mounting hardware.

This product must be secured to the transom with the required mounting hardware. If the outboard strikes an underwater object, the required mounting hardware prevents the outboard from propelling off the transom. A decal on the swivel bracket reminds the installer of the potential hazard.




52375

1. Place the outboard on the centerline of the transom.



27005

2. Tighten the transom bracket clamp screws.




28501

3. Secure the outboard to the transom with the two transom bracket clamp screws (step 2) and two mounting bolts (steps a through d, following).
 - a. Drill two 7.9 mm (5/16 in.) holes through the transom bracket mounting holes.

INSTALLATION

- b. Fasten the outboard with two bolts, flat washers, and locknuts.
- c. Use a marine waterproofing sealer in the holes and around the bolts to make the installation watertight.
- d. Tighten the bolts to the specified torque.



- a - Bolts (2)
- b - Washers (2)
- c - Locknuts (2)
- d - Transom bracket clamp screws (2)

Description	Nm	lb-in.	lb-ft
Transom bracket mounting bolts	13.5	120	–

Steering Link Rod Installation

⚠ WARNING

Improper fasteners or improper installation procedures can result in loosening or disengagement of the steering link rod. This can cause a sudden, unexpected loss of boat control, resulting in serious injury or death due to occupants being thrown within or out of the boat. Always use required components and follow instructions and torque procedures.

IMPORTANT: The steering link rod that connects the steering cable to the engine must be fastened using the steering link rod fastening hardware supplied with the engine. Never replace the locknuts with non-locking nuts. Non-locking nuts may loosen and vibrate off, allowing the link rod to disengage.


1. Ensure that the seal is installed over the steering cable on the port side of the tilt tube.
2. Attach the steering link rod to the steering cable with a flat washer and a nylon insert locknut. Tighten the locknut until it seats, then back nut off 1/4 turn.

Description	Nm	lb-in.	lb-ft
Nylon insert locknut at the steering cable	Tighten until it seats, then back off 1/4 turn		

3. Attach the steering link rod to the steering bracket with one screw, two washers (note placement), a spacer, and a locknut.
4. Tighten the locknut at the steering bracket to the specified torque.

INSTALLATION

Description	Nm	lb-in.	lb-ft
Nylon insert locknut at the steering bracket	27	-	20



10386

- a** - Screw
- b** - Flat washer
- c** - Spacer
- d** - Nylon insert locknut
- e** - Steering bracket - install steering link rod into side hole
- f** - Nylon insert locknut (tighten until seats, then back off 1/4 turn)
- g** - Seal

INSTALLATION

Remote Control Connections

Remote Wire Harness Connection

1. Remove two screws with captive washers to remove the rigging ingress cover.





a - Screws with captive washers (2)

b - Rigging ingress cover

78008

2. Remove two screws with captive washers to remove the cable receptacle bracket from the bottom cowl.

NOTE: Two nuts sit inside the bottom cowl, to receive the screws. These nuts are loose, and may be removed to prevent loss during harness installation.



a - Cable receptacle bracket

b - Screws with captive washers (2)


c - Nuts (2)

78009

3. Route the remote wiring harness through the rubber grommet.
4. Connect the 8-pin connector to the engine harness, and secure the connection with the reusable cable tie.

INSTALLATION

5. Secure the remote wiring harness in the two clips on the electrical bracket.




78011

- a** - Clips on electrical bracket (2)
- b** - Engine harness
- c** - 8-pin connector
- d** - Reusable cable tie
- e** - Rubber grommet

INSTALLATION

- Place the two hex nuts in the bottom cowl, and use two screws with captive washers to install the cable receptacle bracket. Tighten the screws to the specified torque.



78009

- a** - Cable receptacle bracket
- b** - Screws with captive washers (2)
- c** - Nuts (2)

Description	Nm	lb-in.	lb-ft
Cable receptacle bracket screws	6	53	–

Throttle Cable Installation

Install the cables into the remote control following the instructions provided with the remote control.


- Position the remote control handle into full forward throttle position.

NOTE: *The throttle cable is the second cable to move when moving the control box out of neutral.*

- Attach the throttle cable end guide to the throttle lever with a washer and cotter pin retainer.
- Adjust the cable barrel so that the installed throttle cable will hold the throttle level against the throttle stop.

INSTALLATION

4. Position the throttle cable into the rubber grommet and place the cable barrel into the barrel receptacle.




78012

- a** - Flat washer
- b** - Cotter pin retainer
- c** - Throttle lever
- d** - Throttle cable end guide
- e** - Rubber grommet
- f** - Cable barrel
- g** - Barrel receptacle

5. Move the remote control handle to the full throttle position and check to make sure that the throttle cable end guide does not contact the remote control harness.

IMPORTANT: Make sure that the throttle cable end guide does not contact the remote wiring harness when the throttle cable is at full throttle position. If necessary, reposition the remote wiring harness.



- a** - Throttle cable end guide
- b** - Remote wiring harness
- c** - Interference


78144

Shift Cable Installation

Install the cables into the remote control following the instructions provided with the remote control.

INSTALLATION


1. Locate the center point of the slack or lost motion that exists in the shift cable as follows:
 - a. Move the remote control handle from neutral into forward and advance the handle to full speed position. Slowly return the handle back to neutral. Place a mark ("a") on the cable next to the end guide.
 - b. Move the remote control handle from neutral into reverse and advance the handle to full speed position. Slowly return the handle back to neutral. Place a mark ("b") on the cable next to the end guide.
 - c. Make a center mark ("c"), midway between marks ("a" and "b"). Align the end guide with this center mark when installing the cable to the engine.



2. Manually shift the outboard into neutral (propeller will rotate freely).
3. Position the remote control handle into neutral.
4. Attach the shift cable to the shift lever with a washer and cotter pin retainer.
5. Adjust the cable barrel so the center mark on the cable is aligned with the end guide when the cable barrel is placed in the barrel receptacle.

INSTALLATION


6. Position the shift cable into the rubber grommet and place the cable barrel into the barrel receptacle.



78014

- a** - Flat washer
- b** - Cotter pin retainer
- c** - Shift cable end guide
- d** - Center mark
- e** - Rubber grommet
- f** - Cable barrel
- g** - Barrel receptacle

7. Install the rigging ingress cover with two screws with captive washers. Tighten the screws to the specified torque.



78029

- a** - Rigging ingress cover
- b** - Screws with captive washers (2)

Description	Nm	lb-in.	lb-ft
Rigging ingress cover screw	6	53	-

8. Check shift cable adjustments as follows:

INSTALLATION

- a. Shift the remote control into forward. The propeller shaft should be locked in gear. If not, adjust the barrel closer to the cable guide.
- b. Shift the remote control into reverse while turning propeller. The propeller shaft should be locked in gear. If not, adjust the barrel away from the cable guide. Repeat steps a through c.
- c. Shift the remote control back to neutral. The propeller shaft should turn freely without drag. If not, adjust the barrel closer to the cable guide. Repeat steps a through c.

Battery Installation (Electric Start Models)

Battery Installation


Follow the battery manufacturer's instructions carefully.

- Mount the battery in the boat so it is secured against movement, preferably in a battery box.
- Make sure the battery is equipped with a nonconductive shield to prevent accidental shorting of the battery terminals.

NOTE: Electric starting outboards must have the battery cables connected to a battery whenever the engine is running, even if started manually, as damage to the charging system could result.

Battery Cable Connections

1. Connect the red battery cable to the (+) positive battery terminal.
2. Connect the black battery cable to the (-) negative battery terminal.



TRANSPORTING

Aquatic Invasive Species (AIS)



STOP AQUATIC HITCHHIKERS!™
Be A Good Steward. Clean. Drain. Dry.

For additional information, visit StopAquaticHitchhikers.org.

About AIS

AIS and their spread can detrimentally impact the boating experience and the future of the boating lifestyle. Reducing the spread of AIS has led to significant national efforts to inspect boats moving between water bodies or across state and federal boundaries and could lead to delayed or denied access if AIS are suspected or found on board.

AIS include plant life such as Eurasian watermilfoil and water hyacinth, and animals such as spiny water flea, quagga, and zebra mussels. AIS may vary in size from microscopic, to easily visible to the naked eye, and can live in residual water or mud. These species damage ecosystems and negatively impact fishing by depleting natural food resources, altering the water environment, and changing the structure of the ecosystem.

The impact of AIS has already resulted in the limiting of boating access to many waterways throughout North America, the closure of public boat ramps, and the reduction of availability for fishing and boating across the United States. Many federal, state, and local agencies have enacted laws and regulations for inspections, permits, launch availability, and water access for vessels entering public waterways.

Boats and associated equipment are major contributors to the spread of AIS. Boats that have come into contact with AIS can become a means of transportation through attachment and entrapment.

Boat Cleaning and AIS

Water passes in and out of the space under the engine's lower cowls during normal operation of the boat. When flushing and cleaning the boat to control the spread of AIS, pay attention to this space by directing flushing water into the spaces under the lower cowl.

The engine cooling system can be flushed by operating the engine with the appropriate flushing attachment and introducing heated water to the engine.

Region-Specific Information



For more information about the control of AIS in a specific region, please contact the local area wildlife conservation office or local governmental natural resources office.

TRANSPORTING

Carrying, Storing, and Transporting an Outboard Removed from the Boat

IMPORTANT: Ensure that the proper procedures are followed for transportation and storage of the outboard, to avoid the possibility of oil leaks.

1. With the outboard still in the water, disconnect the remote fuel line and run the engine until it stops.
2. Install the protector cap over the fuel inlet connector.



78015

- a** - Fuel inlet connector
- b** - Protective cap


3. Remove the outboard and hold it upright until the water is drained out.




27010

TRANSPORTING


4. Carry, transport, or store the outboard in any of the three positions shown. These positions will prevent oil from draining out of the crankcase.



- a - Upright position
- b - Tiller handle down
- c - Front side down



5. Never carry, store, or transport the outboard in the two positions shown. Engine damage could result from oil draining out of the crankcase.



- a - Tiller handle up
- b - Front side up


Trailing a Boat with Installed Outboard

IMPORTANT: The tilt lock lever should be used to lock the outboard down when trailering. This will prevent the outboard from bouncing and causing possible damage to the outboard.

Trail the boat with the outboard tilted down in a vertical operating position.

TRANSPORTING

If additional ground clearance is required, the outboard should be tilted up using an accessory outboard support device. Contact a local Mercury dealer for recommendations. Additional clearance may be required for railroad crossings, driveways, and trailer bouncing.



Shift the outboard to forward gear. This prevents the propeller from spinning freely.

FUEL AND OIL

Fuel Requirements

IMPORTANT: Use of improper gasoline can damage an engine. Engine damage resulting from the use of improper gasoline is considered misuse of the engine and will not be covered under the Limited Warranty or legal guarantee (if applicable).

Fuel Ratings

Mercury outboard engines will operate satisfactorily with any major brand of unleaded gasoline that meets the following specifications:

- **USA and Canada** - A posted pump octane rating of 87 (R+M)/2, minimum, for most models. Premium gasoline 91 (R+M)/2 octane is also acceptable for most models. **Do not** use leaded gasoline.
- **Outside USA and Canada** - A posted pump octane rating of 91 RON, minimum, for most models. Premium gasoline (95 RON) is also acceptable for all models. **Do not** use leaded gasoline.

Using Reformulated (Oxygenated) Gasoline (USA Only)

Reformulated gasoline is required in certain areas of the USA and is acceptable for use in Mercury Marine engines. The only oxygenate currently in use in the USA is alcohol (ethanol, methanol, or butanol).

Gasoline Containing Alcohol

Bu16 Butanol Fuel Blends

Fuel blends of up to 16.1% butanol (Bu16) that meet the published Mercury Marine fuel rating requirements are an acceptable substitute for unleaded gasoline. Contact the boat manufacturer for specific recommendations on the boat's fuel system components (fuel tanks, fuel lines, and fittings).

Methanol and Ethanol Fuel Blends

IMPORTANT: The fuel system components on Mercury Marine engines will withstand up to 10% alcohol (methanol or ethanol) content in the gasoline. Some boat fuel systems may not be capable of withstanding the same percentage of alcohol. Contact the boat manufacturer for specific recommendations for boat-specific fuel system components (fuel tanks, fuel lines, and fittings).

Be aware that gasoline containing methanol or ethanol may cause increased:

- Corrosion of metal parts
- Deterioration of rubber or plastic parts
- Fuel permeation through the rubber fuel lines
- Likelihood of phase separation (water and alcohol separating from the gasoline in the fuel tank)

FUEL AND OIL

⚠ WARNING

Fuel leakage is a fire or explosion hazard, which can cause serious injury or death. Periodically inspect all fuel system components for leaks, softening, hardening, swelling, or corrosion, particularly after storage. Any sign of leakage or deterioration requires replacement before further engine operation.


IMPORTANT: When using gasoline that contains or might contain methanol or ethanol, increase the frequency of inspection for leaks and abnormalities.

IMPORTANT: When operating a Mercury Marine engine on gasoline containing methanol or ethanol, do not store the gasoline in the fuel tank for long periods. Cars normally consume these blended fuels before they can absorb enough moisture to cause trouble; boats often sit idle long enough for phase separation to take place. Internal corrosion may occur during storage if alcohol has washed protective oil films from internal components.

Fuel Demand Valve (FDV) Requirement

Whenever a pressurized fuel tank is used, a fuel demand valve is required to be installed in the fuel hose between the fuel tank and primer bulb. The fuel demand valve prevents pressurized fuel from entering the engine and causing a fuel system overflow or possible fuel spillage.

The fuel demand valve has a manual release. The manual release can be used (pushed in) to open (bypass) the valve in case of a fuel blockage in the valve.



- a** - Fuel demand valve - installed in the fuel hose between the fuel tank and primer bulb
- b** - Manual release
- c** - Vent/water drain holes

Fuel Tank

EPA Pressurized Portable Fuel Tank Requirements

The Environmental Protection Agency (EPA) requires portable fuel systems that are produced after January 1, 2011, for use with outboard engines to remain fully sealed (pressurized) up to 34.4 kPa (5.0 psi). These tanks may contain the following:

- An air inlet that opens to allow air to enter as the fuel is drawn out of the tank.
- An air outlet that opens (vents) to the atmosphere if pressure exceeds 34.4 kPa (5.0 psi).

FUEL AND OIL

Mercury Marine's Pressurized Portable Fuel Tank

Mercury Marine has created a portable pressurized fuel tank that meets the preceding EPA requirements. This fuel tank is available as an accessory and is provided with certain portable outboard models.

Special Features of the Portable Fuel Tank


- The fuel tank has a two-way valve that allows air to enter the tank as the fuel is drawn to the engine, and also opens to vent to the atmosphere if internal pressure in the tank exceeds 34.4 kPa (5.0 psi). A hissing noise may be heard as the tank vents to the atmosphere. This is normal.
- The fuel tank includes a fuel demand valve that prevents pressurized fuel from entering the engine and causing a fuel system overflow or possible fuel spillage.
- The fuel cap has a built-in device that prevents overtightening. An audible click signifies that the cap is fully seated.
- The fuel tank has a manual vent screw that should be closed for transportation and open for operation and cap removal.

Since sealed fuel tanks are not vented, they will expand and contract as the fuel expands and contracts during heating and cooling cycles of the outside air. This is normal.

Removing the Fuel Cap

IMPORTANT: Contents may be under pressure. Rotate the fuel cap 1/4 turn to relieve pressure before opening.

1. Open the manual vent screw on top of the fuel cap.
2. Turn the fuel cap until it contacts the tab lock.
3. Press down on the tab lock. Rotate the fuel cap 1/4 turn to relieve the pressure.
4. Press down on the tab lock again and remove the cap.



- a** - Fuel cap
- b** - Manual vent screw
- c** - Tab lock

Using the Pressurized Portable Fuel Tank

- When installing the fuel tank cap, turn the cap to the right until there is an audible click. The click signals that the fuel cap is fully seated. A built-in device prevents overtightening.

FUEL AND OIL

- Open the manual vent screw on top of the cap for operation and cap removal. Close the manual vent screw for transportation.
- For fuel hoses that have quick disconnects, disconnect the fuel line from the engine or fuel tank when not in use.
- For fueling instructions, refer to **Filling Fuel Tank**.

Filling Fuel Tank

⚠ WARNING

Avoid serious injury or death from a gasoline fire or explosion. Use caution when filling fuel tanks. Always stop the engine and do not smoke or allow open flames or sparks in the area while filling fuel tanks.

Fill the fuel tanks outdoors away from heat, sparks, and open flames.

Remove the portable fuel tanks from the boat to fill them.

Always stop the engine before filling the tanks.

Do not completely fill the fuel tanks. Leave approximately 10% of the tank volume unfilled. Fuel will expand in volume as its temperature rises and can leak under pressure if the tank is completely filled.

Portable Fuel Tank Placement in the Boat

Place the fuel tank in the boat so the vent is higher than the fuel level under normal boat operating conditions.

Low Permeation Fuel Hose Requirement

Required for outboards manufactured for sale, sold, or offered for sale in the United States.

- The Environmental Protection Agency (EPA) requires that any outboard manufactured after January 1, 2009, must use low permeation fuel hose for the primary fuel hose connecting the fuel tank to the outboard.
- Low permeation hose is USCG Type B1-15 or Type A1-15, defined as not exceeding 15 g/m²/24 h with CE 10 fuel at 23 °C as specified in SAE J 1527 - marine fuel hose.

Engine Oil Recommendations


IMPORTANT: Nondetergent oils, multiviscosity oils (other than Mercury or Quicksilver NMMA FC-W certified oil or a major brand NMMA FC-W certified oil), full synthetic oils, low quality oils, and oils that contain solid additives are not recommended.

Mercury or Quicksilver NMMA™ FC-W® or NMMA FC-W catalyst compatible certified SAE® 10W-30 Mineral Marine 4-Stroke Engine Oil or SAE 10W-30 Synthetic Blend Marine 4-Stroke Engine Oil is recommended for general all-temperature use.

FUEL AND OIL

As an optional choice, Mercury or Quicksilver SAE 25W-40 Mineral Marine 4-Stroke Engine Oil or SAE 25W-40 Synthetic Blend Marine 4-Stroke engine oil may be used when temperatures are above 4 °C (40 °F).

If the recommended Mercury or Quicksilver NMMA FC-W certified oils are not available, a major outboard manufacturer's brand of NMMA FC-W certified 4-Stroke outboard oil of similar viscosity may be used.



FUEL AND OIL

Notes:

FEATURES AND CONTROLS


Tiller Handle Features

- A decal on the tiller handle provides a quick reference guide for starting the engine.



78098


- Tiller handle tilt - The handle can be tilted 180° for convenient handling during transportation and storage.



28535

FEATURES AND CONTROLS

- Tiller lock release lever - Push the lever to move tiller handle from one position to another.



a - Tiller lock release lever

3274

- Tiller handle lock cap - Remove the lock cap to allow the tiller handle to lock in the up position. Push the tiller lock release lever to release the handle from the locked up position.

NOTE: Use a small flat-blade screwdriver to remove the cap. Retain the cap to prevent dirt and grime from fouling the lock mechanism, when the tiller handle does not need to be locked in the up position.



78127

- a -** Lock cap installed
- b -** Lock cap removed

FEATURES AND CONTROLS

- Lanyard stop switch - Refer to **General Information - Lanyard Stop Switch**.




78101

- Engine stop switch - Push in to stop the engine.



78129

- Throttle grip - Controls the engine speed and shifting.



57674


- a** - Forward gear throttle
- b** - Reverse gear throttle

FEATURES AND CONTROLS

⚠ WARNING

Avoid serious injury or death from unattended boat operation. Even with throttle grip friction and steering friction applied, the operator must remain at the controls and be ready to evade hazards.

- Throttle grip friction knob - Turn the friction knob to set and maintain the throttle at a desired speed. Turn the knob clockwise to increase friction or turn the knob counterclockwise to decrease friction.




- a** - Loosen friction (counterclockwise)
- b** - Tighten friction (clockwise)

IMPORTANT: Avoid engine flooding - Do not rotate the throttle grip while the engine is not running. Doing so will inject fuel into the engine and cause a possible hard starting flooded condition.

⚠ WARNING

Insufficient friction adjustment can cause serious injury or death due to loss of boat control. When setting the friction adjustment, maintain sufficient steering friction to prevent the outboard from steering into a full turn if the tiller handle or steering wheel is released.

- Steering friction adjustment (copilot) - Adjust this lever to achieve the desired friction on the tiller handle. Move the lever to the starboard to increase the friction, or move the lever to the port to decrease the friction. A quick reference decal is located on the transom clamp.



- a** - Friction adjustment lever (copilot)
- b** - Decal
- c** - Increase friction
- d** - Decrease friction

FEATURES AND CONTROLS

- Throttle only button - The "THROTTLE ONLY" button is located on the starboard side of the engine. Pressing the button while the outboard is in neutral disables the gear shift control of the tiller handle.



28550


Warning System

Warning Horn Location

A warning horn is located near the front of the engine, under the cowl. On remote control models, an additional warning horn is located inside the remote control or connected to the ignition key switch.

Warning Light

The warning light is located on the front of the engine, just below the top cowl. It will turn on or flash to alert the operator to the warning system situations listed in **Warning System Operation**.



78114

Warning System Operation

The warning horn will emit either a continuous beep or intermittent short beeps and engine speed will be limited. This will alert the operator and help identify the following listed situations.

Function	Warning Horn	Warning Light	Description	RPM Limit
Start up	One second		System test	None


FEATURES AND CONTROLS

Function	Warning Horn	Warning Light	Description	RPM Limit
Overheat	Continuous for six seconds	On	Engine overheat	2800
Low oil pressure			Low oil pressure	
Sensor error	Six beeps no repeats	Six flashes repeats every five minutes	Engine sensor fault	
Overspeed*	None		Engine speed too high	Engine misfire may be noticed
Restrictor (8hp models)	Six beeps no repeats	Six flashes repeats every five minutes	Restrictor missing	2800

*Refer to the **Specifications** table for RPM limits.

Engine Overheat

If the engine overheats, immediately reduce throttle speed to idle. Shift the outboard into neutral and check for a steady stream of water coming out of the water pump indicator hole.



If no water is coming out of the water pump indicator hole, or flow is intermittent, stop the engine and check the cooling water intake holes for obstruction. If no obstruction is found, there may be a blockage in the cooling system or a water pump problem. Operating the engine while overheated will cause engine damage.

If a steady flow of water is coming out of the water pump indicator hole and the engine continues to overheat, service is required. Operating an overheated engine will cause engine damage.

FEATURES AND CONTROLS

NOTE: Should overheating occur while on the water, stop the engine and allow it to cool down. This will usually allow some additional low speed (idle) running time before the engine starts to overheat again.

Engine Overspeed Limiter

Some causes of engine overspeed are:

- Propeller ventilation
- A propeller that has an incorrect pitch or diameter
- Propeller hub slippage
- Outboard mounted too high on the transom
- Outboard tilted out beyond a vertical position
- Cavitation of the propeller due to rough water or an obstruction in the boat hull

When the engine overspeed limiter is activated, the engine timing will be momentarily retarded to decrease the engine speed. Excessive overspeed will result in the momentary removal of ignition to prevent operation above the RPM limit. Refer to **General Information - Specifications**.

Low Oil Pressure

The warning system will be activated if the oil pressure drops too low. First, stop the engine and check the oil level. Add oil if necessary. If the oil is at the recommended level and the warning horn continues to sound, consult an authorized dealer. The engine speed will be limited to 2800 RPM, but it is advisable to completely avoid operating the engine until the problem is fixed.

Sensor and Restrictor Error

The computer controlled CDI (capacitor discharge ignition) monitors various sensors on the engine and when a sensor is not within the normal operating range, the computer controlled CDI will limit the engine RPM to 2800, the warning light will flash, and the warning horn will beep six times every five minutes.


A restrictor in the air intake induction system restricts the amount of air that can enter the induction system. The restrictor cannot be removed to gain more horsepower. If the restrictor is removed, the computer controlled CDI will limit the engine RPM to 2800, the warning light will flash, and the warning horn will beep six times every five minutes.

FEATURES AND CONTROLS

Manual Tilt Features and Operation


Manual Tilt Features

- Tilt lock knob - Locks the engine in the full up position. Refer to **Full Up Position**.



28564

- Trim position knob - Sets the outboard operating angle. Refer to **Outboard Operating Angle**.




28551

Full Up Position

Tilting to the Full Up Position


1. Stop the engine.
2. Shift the outboard into forward gear.
3. Take hold of the top cowl grip and raise the outboard to the full up position.



45600

FEATURES AND CONTROLS


4. Pull out on the tilt lock knob and move it to the lock position. The outboard cannot be lowered while the tilt lock knob is in the lock position.



a - Tilt lock knob in lock position

Lowering to the Run Position

1. Move the tilt lock knob to the unlock position.



a - Tilt lock knob in unlock position

2. Raise the outboard to the tilt release position, and gently lower the outboard to the preset trim position.

Shallow Water Drive Position

There are three (3) shallow water drive positions that enable the outboard to be tilted up to prevent hitting the bottom.

To engage a shallow water drive position:


1. Stop the engine.
2. Shift the outboard into neutral.
3. Tilt the outboard up to one of the shallow water drive positions.
4. Ensure the water intake is submerged.

To release the shallow water drive position:

1. Stop the engine.
2. Tilt the outboard up to one of the tilt release positions.

FEATURES AND CONTROLS

3. Gently lower the outboard to the preset transom angle.




- a** - Shallow water drive positions
- b** - Tilt release positions
- c** - Water Intake

FEATURES AND CONTROLS

Outboard Operating Angle

The proper outboard operating angle allows the boat to achieve optimum performance, stability, and minimize steering effort. Adjust the operating angle so the outboard is positioned to run perpendicular to the water when the boat is running at full speed. This allows the boat to be driven parallel to the water.



- a** - Too much angle (stern down - bow up)
- b** - Not enough angle (stern up - bow down)
- c** - Angle adjusted properly (bow slightly up)

Adjusting the Operating Angle


Refer to **Outboard Operating Angle Considerations** for the benefits and detriments of changing the operating angle either in or out from the middle setting.

The vertical operating angle of the outboard is adjusted by changing the position of the preset tilt knob in one of the three adjustment holes provided.

1. Stop the engine.
2. Shift the outboard into forward.
3. Raise the engine to one of the tilt release positions.
4. Change the preset knob position to the desired angle setting (1, 2, or 3).

FEATURES AND CONTROLS

5. Lower the outboard to the new transom angle position.



39227

- a** - Transom angle settings
- b** - Tilt release position

Outboard Operating Angle Considerations

Before adjusting the outboard operating angle from the middle of the range, consider the following benefits and detriments of changing the angle.

Adjusting the outboard close to the boat transom (down or in) can:

- Lower the bow.
- Result in quicker planing off, especially with a heavy load or a stern heavy boat.
- Generally improve the ride in choppy water.
- Increase steering torque or pull to the right (with the normal right-hand rotation propeller).
- In excess, lower the bow of some boats to a point where they begin to plow with their bow in the water while on plane. This can result in an unexpected turn in either direction (called bow steering or oversteering), if any turn is attempted or if a significant wave is encountered.


Adjusting the outboard away from the boat transom (out or up) can:

- Lift the bow out of the water
- Generally increase top speed
- Increase clearance over submerged objects or a shallow bottom
- Increase steering torque or pull to the left at a normal installation height (with the normal right-hand rotation propeller)
- Cause engine overheating if any cooling water intake holes are above the waterline
- In excess, cause boat porpoising (bouncing) or propeller ventilation

FEATURES AND CONTROLS

Trim Tab Adjustment

Propeller steering torque may cause a boat to pull in one direction. Steering torque normally occurs at or above planing speeds. Higher speed causes higher steering torque loads. The trim tab can compensate for normal steering torque in many cases and can be adjusted within limits to reduce any unequal steering effort.



NOTE: Trim tab adjustment will have little effect reducing steering torque if the outboard is installed with the anti-ventilation plate approximately 50 mm (2 in.) or more above the boat bottom.

Operate the boat at normal cruising speed and trim position. Turn the boat left and right and note the direction the boat turns more easily.

Making Adjustments

NOTE: If adjustment is necessary, make small adjustments at a time.

1. Loosen the trim tab fastener.
2. Make only a small adjustment.
 - If the boat turns more easily to the left, move the trailing edge of the trim tab to the left.
 - If the boat turns more easily to the right, move the trailing edge of the trim tab to the right.
3. Tighten the fastener and test. If steering torque is still evident, repeat the process.

FEATURES AND CONTROLS

Notes:

OPERATION

Engine Break-in Procedure

IMPORTANT: Failure to follow the engine break-in procedures can result in poor performance throughout the life of the engine and can cause engine damage. Always follow break-in procedures.

1. For the first two hours of operation, run the engine at varied throttle settings up to 4500 RPM or three-quarter throttle. Changes in throttle should be gradual and extended time at idle should be avoided.
2. For the next eight hours of operation, avoid continuous operation at full throttle for more than five minutes at a time.

Prestarting Checklist

Before starting the outboard:

- Review the **Safe Boating Recommendations** in the **Important Safety Information** section of this manual.
- Perform all additional daily inspections and checks listed in **Maintenance - Inspection and Maintenance Schedule**.
- If the engine has less than 10 hours of operation, review the **Engine Break-in Procedure**.
- Ensure that the fuel supply is OK.

Prestarting Instructions

1. Check the engine oil level. Refer to **Maintenance - Checking Engine Oil**.




78007

2. Install the top cowl. Refer to **Maintenance - Top Cowl Removal and Installation**.

OPERATION

3. Connect the remote fuel hose to the fuel inlet connector on the outboard. Make sure the connector is snapped into place.




78112

- a** - Fuel inlet connector
- b** - Fuel hose

NOTICE

Without sufficient cooling water, the engine, the water pump, and other components will overheat and suffer damage. Provide a sufficient supply of water to the water inlets during operation.

4. Make sure the cooling water intake is submerged.




26837

Starting the Engine - Tiller Handle Models

Before starting, read the **Prestarting Checklist** and **Prestarting Instructions**.

OPERATION


1. Open the fuel tank vent screw on the manual venting type tanks.



- a - Fuel cap
- b - Manual vent screw
- c - Tab lock

IMPORTANT: To prevent engine flooding, do not squeeze the primer bulb after the engine has warmed up.

2. Position the fuel line primer bulb so the arrow on the side of the bulb is pointing up. Squeeze the fuel line primer bulb several times until it feels firm.



3. Slide the lanyard clip onto the stop switch. This is the operating position.



Lanyard clip on the stop switch

OPERATION


- Set the tiller handle gear shift to the neutral start position.



57677

IMPORTANT: Outboards with battery charging capabilities must not be operated with battery cables disconnected from the battery. Damage to the charging system may result.

- Manual starting models** - Pull the starter rope slowly until the starter engages, then pull rapidly to crank the engine. Allow the rope to return slowly. Repeat until the engine starts.



28586


- Electric starting models** - Turn the ignition key to crank the engine. Release the key when the engine starts. Do not operate the starter motor continuously for longer than ten seconds at a time. If the engine fails to start, wait 30 seconds and try again.
- Flooded engine** - If the engine will not start, push in the "THROTTLE ONLY" button, advance the throttle grip to fast idle, and attempt to start the engine. After the engine has started, immediately reduce the throttle speed to idle.



28550

OPERATION

8. Check for a steady stream of water flowing out of the water pump indicator.



IMPORTANT: If no water is coming out of the water pump indicator, stop the engine and check the cooling water intake for obstruction. No obstruction may indicate a water pump failure or blockage in the cooling system. These conditions will cause the engine to overheat. Have the outboard checked by a certified dealer. Operating the engine while overheated will cause serious engine damage.


Warming Up the Engine

Before beginning operation, allow the engine to warm up at idling speed for three minutes.

Starting the Engine - Remote Control Models

Before starting, read the **Prestarting Checklist** and **Prestarting Instructions**.


1. Open the fuel tank vent screw on the manual venting type tanks.




- a** - Fuel cap
- b** - Manual vent screw
- c** - Tab lock

OPERATION

- Position the fuel line primer bulb so the arrow on the side of the bulb is pointing up. Squeeze the fuel line primer bulb several times until it feels firm.



- Set the lanyard stop switch to the **RUN** position. Refer to **Important Safety Information - Lanyard Stop Switch**.



- Verify the remote control handle is in the neutral position.




IMPORTANT: Outboards with battery charging capabilities must not be operated with battery cables disconnected from the battery. Damage to the charging system may result.


- Turn the ignition key to the **START** position and start the engine.
 - If the engine fails to start in ten seconds, wait 30 seconds and try again.

OPERATION

- If the engine begins to stall, use the throttle-only feature and advance the throttle. Do not exceed 2000 RPM.



6. Check for a steady stream of water flowing out of the water pump indicator.



IMPORTANT: If no water is coming out of the water pump indicator, stop the engine and check the cooling water intake for obstruction. No obstruction may indicate a water pump failure or blockage in the cooling system. These conditions will cause the engine to overheat. Have the outboard checked by a certified dealer. Operating the engine while overheated will cause serious engine damage.

Warming Up the Engine

Before beginning operation, allow the engine to warm up at idle speed for three minutes.


Emergency Starting

⚠ WARNING

The start-in-gear protection device is inoperative when starting the engine with the emergency starter rope. Set the engine speed at idle and the gear shift in neutral to prevent the outboard from starting in gear.

OPERATION

IMPORTANT: The flywheel cover is secured to the engine by three 10 mm hex head screws. The wrench that was supplied with the engine can be used to remove these screws. To assemble the wrench, slide the handle through the holes in the wrench body, as shown. The smaller end of the wrench body is a 10 mm hex socket that will fit the screws.




- a** - Wrench body
- b** - Handle
- c** - 10 mm hex socket

If the starter system fails, use the spare starter rope (provided) and follow this procedure.

1. Shift the outboard into neutral.
2. Remove the top cowl.
3. Remove the flywheel cover:
 - a. Cut the cable tie that retains the stator wires to the flywheel cover.
 - b. Remove the crankcase breather hose from the clip on the flywheel cover.
 - c. Remove one phillips head screw and retaining tab that secures the neutral interlock cable (start-in-gear protection) to the flywheel cover, and remove the cable from the cover.

OPERATION

- d. Remove the three screws (two short and one long) and washers holding the flywheel cover.



78013

- a** - Flywheel cover
- b** - Cable tie
- c** - Short screw and washer
- d** - Long screw and washer
- e** - Phillips head screw and retaining tab
- f** - Clip for crankcase breather hose

- e. Completely remove the flywheel cover from the engine.
f. Use the long screw and washer to secure the idle air control (IAC) valve to the engine.




- a** - Idle air control valve
- b** - Long screw and washer

78145

OPERATION

- g. Route the crankcase breather hose to the starboard side of the engine oil dipstick to prevent it from interfering with the flywheel.



- a - Flywheel
- b - Engine oil dipstick
- c - Crankcase breather hose

- h. Retain all other parts for later reassembly
4. Ensure that the lanyard stop switch is in the **RUN** position.
5. Refer to **Starting the Engine**, and:
 - a. Open the fuel tank vent screw.
 - b. Prime the fuel line.
6. **Remote control models:** Ensure that the key switch is in the **ON** position and the control is in neutral.

⚠ WARNING

The exposed moving flywheel can cause serious injury. Keep hands, hair, clothing, tools, and other objects away from the engine when starting or running the engine. Do not attempt to reinstall the flywheel cover or top cowl when the engine is running.

7. Place the starter rope knot into the flywheel notch, and wind the rope clockwise around the flywheel.



8. Pull the starter rope quickly but carefully.
9. If the engine does not start, repeat steps 4 through 8.
10. Do not attempt to reinstall the top cowl or any other components until reaching the shore and the engine has been shut off.

OPERATION

Gear Shifting

IMPORTANT: Observe the following:

- **Never shift the outboard into or out of gear unless the engine speed is at idle. Shifting at higher than engine idle speed could cause damage to the gearcase.**
- **Do not shift the outboard into reverse when the forward motion of the boat is greater than a no wake speed. Shifting into reverse at higher boat speeds could cause the engine to stall, and in some situations, this could cause water to be drawn into the cylinders, resulting in severe engine damage.**
- **Do not shift the outboard into reverse when the engine is not running. Damage to the shift linkage could occur.**
- The outboard has three gear shift positions to provide operation: forward (F), neutral (N), and reverse (R).
- **Tiller handle models** - Reduce the engine speed to idle before shifting.



- a** - (F) Forward
- b** - (N) Neutral
- c** - (R) Reverse

- **Remote control models** - When shifting, always stop at the neutral position and allow the engine speed to return to idle.




- Always shift the outboard into gear with a quick motion.

OPERATION


- After shifting the outboard into gear, advance the remote control lever or rotate the throttle grip (tiller handle) to increase speed.

Stopping the Engine

1. **Remote control models** - Reduce the engine speed and shift the outboard to the neutral position. Turn the ignition key to the **OFF** position.



2. **Tiller handle models** - Reduce the engine speed and shift the outboard to the neutral position. Push in the engine stop button or turn the ignition key to the **OFF** position.



Operating in Freezing Temperatures

When an outboard is used or moored in freezing or near freezing temperatures, keep the outboard tilted down, with the gearcase submerged. This prevents any water trapped in the gearcase from freezing and causing possible damage to the water pump and other components.

If there is a chance of ice forming on the water, the outboard should be removed from and completely drained of water, immediately after use. If ice should form inside the outboard driveshaft housing, the ice will block water flow to the engine, causing possible damage.

Operating in Saltwater or Polluted Water

Flush the outboard's internal water passages with fresh water after each use in salty or polluted water. This will prevent a buildup of deposits from clogging the water passages. Refer to **Maintenance - Flushing the Cooling System**.

If the boat is kept moored in the water, always (except in freezing temperatures) tilt the outboard up so the gearcase is completely out of water when not in use.

OPERATION

Wash the outboard exterior (Refer to **Maintenance - Cleaning Care Recommendations**) and flush out the exhaust outlet of the propeller and gearcase with fresh water after each use.

Each month, spray Mercury Precision or Quicksilver Corrosion Guard on external metal surfaces. Exercise care to not spray the corrosion control anodes, as this will reduce the anodes' effectiveness.

Description	Where Used	Part No.
Corrosion Guard	External metal surfaces	92-802878 55

Operating Outboard as an Auxiliary Engine

If the outboard is used as an auxiliary engine, stop the engine and tilt the outboard out of the water when using the main power source.

IMPORTANT: The outboard must be restrained from bouncing while operating the boat using the main power source. Bouncing can damage the outboard and boat transom.

OPERATION

Notes:

MAINTENANCE

EPA Emissions Regulations

All new outboards manufactured by Mercury Marine are certified to the United States Environmental Protection Agency, as conforming to the requirements of the regulations for the control of air pollution from new outboard motors. This certification is contingent on certain adjustments set to factory standards. For this reason, the factory procedure for servicing the product must be strictly followed and, wherever practicable, returned to the original intent of the design. **Maintenance, replacement, or repair of the emission control devices and systems may be performed by any marine spark ignition (SI) engine repair establishment or individual.**

Emission Certification Label

An emission certification label, showing emission levels and engine specifications directly related to emissions, is placed on the engine at the time of manufacture.

MERCURY		EMISSION CONTROL INFORMATION	
THIS ENGINE CONFORMS TO <input type="checkbox"/> CALIFORNIA AND U.S. EPA EMISSION REGULATIONS FOR SPARK IGNITION MARINE ENGINES			
REFER TO OWNERS MANUAL FOR REQUIRED MAINTENANCE SPECIFICATIONS AND ADJUSTMENTS			
IDLE SPEED (in gear): <input type="checkbox"/> L <input type="checkbox"/> H		FAMILY: <input type="checkbox"/>	
<input type="checkbox"/> hp	<input type="checkbox"/> L	HC+NOx:FEL: <input type="checkbox"/> g/kWh	<input type="checkbox"/>
<input type="checkbox"/> kw		CO FEL: <input type="checkbox"/> g/kWh	<input type="checkbox"/>
<input type="checkbox"/>	SPARK PLUG: <input type="checkbox"/>	<input type="checkbox"/>	
	GAP: <input type="checkbox"/>	<input type="checkbox"/>	
LOW PERM/HIGH PERM: <input type="checkbox"/>		<input type="checkbox"/>	

43210

- a** - Idle speed
- b** - Engine horsepower
- c** - Piston displacement
- d** - Engine power - kilowatts
- e** - Date of manufacture
- f** - US EPA engine family name
- g** - Regulated emission limit for the engine family
- h** - Regulated emission limit for the engine family
- i** - Recommended spark plug and gap
- j** - Percent of fuel line permeation

Owner Responsibility

The owner/operator is required to have routine engine maintenance performed to maintain emission levels within prescribed certification standards.

The owner/operator is not to modify the engine in any manner that would alter the horsepower or allow emission levels to exceed their predetermined factory specifications.

MAINTENANCE

Cleaning Care Recommendations

Outboard Care

To keep the outboard in the best operating condition, it is important that it receives the periodic inspections and maintenance listed in the **Inspection and Maintenance Schedule**. Proper maintenance helps ensure the safety of the operator and passengers and retains the engine's dependability.

Record all maintenance performed in the **Maintenance Log** at the back of this book. Save all maintenance work orders and receipts.

Selecting Outboard Replacement Parts

For best results, use only original Mercury Precision or Quicksilver replacement parts and Genuine Lubricants.

Do Not Use Caustic Cleaning Chemicals

IMPORTANT: Do not use caustic cleaning chemicals on the outboard power package. Some cleaning products contain strong caustic agents such as hull cleaners with hydrochloric acid. These cleaners can degrade some of the components they come in contact with including critical steering fasteners.

Damage to steering fasteners may not be obvious during visual inspection and this damage may lead to catastrophic failure. Some caustic cleaning chemicals may cause or accelerate corrosion. Exercise caution when using cleaning chemicals around the engine and follow the recommendations on the packaging of the cleaning product.

Cleaning Gauges

IMPORTANT: Never use high-pressure water to clean gauges.

Routine cleaning of the gauges is recommended to prevent a buildup of salt and other environmental debris. Crystalized salt can scratch the gauge display lens when using a dry or damp cloth. Ensure that the cloth has a sufficient amount of fresh water to dissolve and remove salt or mineral deposits. Do not apply aggressive pressure on the display lens while cleaning.

When water marks cannot be removed with a damp cloth, mix a 50/50 solution of warm water and isopropyl alcohol to clean the display lens. **Do not** use acetone, mineral spirits, turpentine type solvents, or ammonia based cleaning products. The use of strong solvents or detergents may damage the coating, the plastics, or the rubber keys on the gauges.

If the gauge has a sun cover available, install the cover when the unit is not in use to prevent UV damage to the plastic bezels and rubber keys.

Cleaning Remote Controls

IMPORTANT: Never use high-pressure water to clean remote controls.

MAINTENANCE

Routine cleaning of the remote control external surfaces is recommended to prevent a buildup of salt and other environmental debris. Use a cloth towel that has a sufficient amount of fresh water to dissolve and remove salt or mineral deposits.

When water marks cannot be removed with a damp cloth, mix a 50/50 solution of warm water and isopropyl alcohol to clean the remote control. **Do not** use acetone, mineral spirits, turpentine type solvents, or ammonia based cleaning products. The use of strong solvents or detergents may damage the coating, the plastics, or the rubber components on the remote control.


Cleaning Care for Top and Bottom Cowls

IMPORTANT: Dry wiping (wiping the plastic surface when it is dry) will result in minor surface scratches. Always wet the surface before cleaning. Do not use detergents containing hydrochloric acid. Follow the cleaning and waxing procedure.

Cleaning and Waxing Procedure

1. Before washing, rinse the cowls with clean water to remove dirt and dust that may scratch the surface.
2. Wash the cowls with clean water and a mild nonabrasive soap. Use a soft clean cloth when washing.
3. Dry thoroughly with a soft clean cloth.
4. Wax the surface using a nonabrasive automotive polish (polish designed for clear coat finishes). Remove the applied wax by hand using a clean soft cloth.
5. To remove minor scratches, use Mercury Marine Cowl Finishing Compound (92-859026K 1).

IMPORTANT: Do not rinse the cowls with water when the outboard is in a tilted position, as this could allow water to enter the air intakes (if equipped). Always lower the outboard to a vertical position prior to rinsing the cowls.



79394

Cleaning Care for the Powerhead (Saltwater Use)

If the outboard is operated in saltwater, remove the top cowl and flywheel cover. Inspect the powerhead and powerhead components for salt buildup. Wash off any salt buildup from the powerhead and powerhead components with fresh water. Keep water spray out of the air intake and alternator.

MAINTENANCE

After washing, allow the powerhead and components to dry. Apply Quicksilver or Mercury Precision Lubricants Corrosion Guard spray on the external metal surfaces of the powerhead and powerhead components. Do not allow the Corrosion Guard spray to come in contact with the alternator drive belt or belt pulleys.

IMPORTANT: Do not allow lubricant or Corrosion Guard spray to come in contact with the alternator drive belt or the belt pulleys. The alternator drive belt could slip and be damaged if it becomes coated with any lubricant or Corrosion Guard spray.

Description	Where Used	Part No.
Corrosion Guard	External metal surfaces of the powerhead and powerhead components.	92-802878 55

Top Cowl Removal and Installation

Removal

1. Pull out the rear cowl latch.



2. Lift the rear of the cowl to clear the rear latch, and push toward the front to clear the front hook.
3. Lift the top cowl to remove.

Installation

1. Lower the top cowl into position over the engine.
2. Move the cowl toward the front to align the front hook. After the front hook has engaged, move the cowl toward the rear, and push the rear of the cowl down.
3. Push in the latch to secure the top cowl.

Inspection and Maintenance Schedule

Refer to the table below for proper inspections and maintenance intervals.

After each use of the outboard be sure to:

- Wash the power package exterior with fresh water. For precaution information, refer to **Cleaning Care**.
- Flush the outboard cooling system, if operating in salty, polluted, or muddy water. Refer to **Flushing the Cooling System**.

MAINTENANCE

Daily Check
Check that pulling the stop switch lanyard stops the engine.
Check the tightness of the transom clamp bolts (manual tilt models).
Check the steering system for binding.
Inspect the propeller for damage.
Inspect the fuel lines for leaks. Refer to Fuel Line Inspection .
Check the engine oil level. Refer to Checking and Adding Engine Oil .

100 Hour Maintenance (100 Hours or Before Long-Term Storage)	Dealer Item
Add Quickleen to the fuel tank (once per year). Follow the instructions on the Quickleen bottle.	
Inspect the corrosion control anodes. Refer to Corrosion Control Anodes .	
Apply anti-seize to the spark plug threads. Refer to Spark Plug Inspection and Replacement .	
Lubricate all applicable points on the engine identified in Lubrication Points .	
Change the engine oil. Refer to Changing Engine Oil .	
Change the gearcase lubricant. Refer to Gearcase Lubricant .	
Inspect the engine starting battery and cables, if equipped.	X
Inspect the tightness of the outboard mounting hardware.	X
Inspect the thermostat, if operating in salty or brackish water.	X
Replace all filters on the suction side of the fuel system.	X
Lubricate the driveshaft splines.	X











3 Year or 300 Hour Maintenance	Dealer Item
Replace the spark plugs. Refer to Spark Plug Inspection and Replacement .	
Inspect the timing belt.	X
Inspect the wire harness connectors.	X
Check the remote control cable adjustment, if equipped.	X
Replace the high-pressure fuel filter, if equipped.	X
Check the power tilt fluid level, if equipped.	X
Inspect the engine mounts.	X
Replace the water pump impeller. NOTE: <i>Replace the water pump impeller more often, if overheating occurs or reduced water pressure is noted.</i>	X

MAINTENANCE
















Maintenance Schedule Decals

Maintenance Schedule Decal Icons

A maintenance schedule decal is located on the engine to remind the owner or operator when the power package important maintenance items require attention. The following table shows the icons and a general description of the scheduled maintenance items.

Icon	Definition	Icon	Definition
 58249	Replace	 58250	Inspect
 58251	Engine oil and filter	 58252	Gearcase lubricant
 58253	Spark plugs	 58254	Thermostat
 58255	Low-pressure fuel filter	 58256	Anodes
 58257	Accessory drive belt	 58258	Water pump impeller

Maintenance Schedule Decal

MAINTENANCE SCHEDULE		Specifications
FOURSTROKE		Full Throttle RPM: 5000-6000 Neutral Idle RPM: 900-1000
EVERY 100 HOURS OF USE OR ONCE YEARLY		 *In Saltwater: Apply Anti-Seize 27 Nm (20 lb-ft) 0.9 mm (0.035 in.) 803507 Engine Oil 800 ml (27 fl. oz.) 
 INSPECT	 REPLACE	
 Anodes	 Engine Oil and Filter	
 Fuel Filter	 Gearcase Lubricant	
 Thermostat	 Lubrication Points	
EVERY 300 HOURS OF USE OR THREE YEARS		
 REPLACE		
 Spark Plugs*	 Water Pump Impeller	
For additional maintenance and storage preparation see Owner's Manual		 

78193

MAINTENANCE

Battery Inspection

IMPORTANT: Read the safety and maintenance instructions that accompany the engine starting battery.

Inspect the battery at periodic intervals to ensure proper engine starting capability.

1. Verify the engine is off before inspecting the battery.
2. Ensure that the battery is secure against movement.
3. Verify that the battery cable terminals are clean, tight, and correctly installed on the battery (positive to positive and negative to negative).
4. Verify the battery is equipped with a nonconductive shield to prevent accidental shorting of battery terminals.

Flushing the Cooling System

⚠ WARNING

Rotating propellers can cause serious injury or death. Never operate the boat out of the water with a propeller installed. Before installing or removing a propeller, place the drive unit in neutral and activate the lanyard stop switch to prevent the engine from starting. Place a block of wood between the propeller blade and the anti-ventilation plate.

Flush the internal water passages of the outboard with fresh water after each use in salt, polluted, or muddy water. This will help prevent a buildup of deposits from clogging the internal water passages.

IMPORTANT: The engine must be run during flushing in order to open the thermostat and circulate water through the water passages.

1. Remove the propeller. Refer to **Propeller Replacement**.
2. Remove the plug from the flush fitting, and attach a water hose. Turn on the water to half of the maximum flow.



78022

Flush fitting

MAINTENANCE

3. Start the engine and run it at idle speed in the neutral position.


IMPORTANT: Do not run the engine above idle while flushing.

4. Check for a steady stream of water flowing out of the water pump indicator hole. Continue flushing the outboard for 3–5 minutes, carefully monitoring the water supply at all times.
5. Stop the engine, turn off the water, and remove the water hose.
6. Install the plug into the flush fitting.
7. Install the propeller.

Corrosion Control Anode

This outboard has a corrosion control anode installed on the gearcase. An anode helps protect the outboard against galvanic corrosion by sacrificing its metal to be slowly corroded instead of the outboard metals.

The anode requires periodic inspection especially in saltwater, which will accelerate the erosion. To maintain this corrosion protection, always replace the anode before it is completely eroded. Never paint or apply a protective coating on the anode as this will reduce effectiveness of the anode.



28623

Engine Oil


Checking Engine Oil

IMPORTANT: Do not overfill. Be sure that the outboard is upright (not tilted) when checking oil.

1. Turn the engine off.
2. Place the outboard in a level operating position.
3. Remove the top cowl.
4. Remove the dipstick.
5. Wipe the dipstick with a clean rag or towel, and push it back in all the way.

MAINTENANCE

6. Pull the dipstick out again and observe the oil level.




7907

a - Oil level operating range

IMPORTANT: Inspect the oil for signs of contamination. Oil contaminated with water will have a milky color to it; oil contaminated with fuel will have a strong fuel smell. If contaminated oil is noticed, have the engine checked by an authorized Mercury dealer.

7. If the oil level is low, remove the oil filler cap and fill to (but not over) the full mark with the recommended oil.



78006

8. Install the oil filler cap and tighten it securely.

Changing Engine Oil

Engine Oil Capacity

Engine oil capacity is approximately 800 ml (27 fl oz).

Oil Changing Procedure


1. Lock the outboard in the full tilt up position.
2. Position the outboard so the drain hole is facing downward.

MAINTENANCE

3. Remove the drain plug and drain the engine oil into an appropriate container.

IMPORTANT: Do not use a crankcase oil pump when changing the oil or engine damage may occur.


4. After the initial oil has been drained, temporarily install the drain plug. Disengage the tilt lock and lower the outboard. Wait a minute to allow the remaining oil that was trapped in the engine to return to the drain. Return the outboard to the full tilt position and drain the remaining oil.
5. Lubricate the seal on the drain plug with oil and reinstall.



Oil Filling

IMPORTANT: Do not overfill. Be sure that the outboard is upright (not tilted) when checking oil.

1. Remove the oil fill cap and refill with 800 ml (27 fl oz) of oil. Install the oil fill cap.



2. Idle engine for five minutes and check for leaks. Stop the engine and check the oil level on the dipstick. Add oil if necessary.

MAINTENANCE

Fuel System

⚠ WARNING

Fuel is flammable and explosive. Ensure that the key switch is off and the lanyard is positioned so that the engine cannot start. Do not smoke or allow sources of spark or open flame in the area while servicing. Keep the work area well ventilated and avoid prolonged exposure to vapors. Always check for leaks before attempting to start the engine, and wipe up any spilled fuel immediately.

IMPORTANT: Use an approved container to collect and store fuel. Wipe up spilled fuel immediately. Material used to contain spilled fuel must be disposed of in an approved receptacle.

For service on any part of the fuel system:

1. **Before service work:** Stop the engine and disconnect the battery.
2. **During service work:** Perform fuel system service in a well-ventilated area.
3. **After service work:** Inspect all completed service work for signs of fuel leakage.

Fuel Line Inspection

Visually inspect the fuel line and primer bulb for cracks, swelling, leaks, hardness, or other signs of deterioration or damage. If any of these conditions are found, the fuel line or primer bulb must be replaced.

Fuel Line Filter

IMPORTANT: Inspect for fuel leakage from the filter connections by squeezing the primer bulb until it is firm, forcing fuel into the filter.

Inspect the fuel line filter. If the filter appears to be contaminated, remove and replace.



78212

MAINTENANCE


Gearcase Lubrication

When adding or changing gearcase lubricant, visually check for the presence of water in the lubricant. If water is present, it may have settled to the bottom and will drain out prior to the lubricant, or it may be mixed with the lubricant, giving it a milky colored appearance. If water is noticed, have the gearcase checked by an authorized dealer. Water in the lubricant may result in premature bearing failure or, in freezing temperatures, will turn to ice and damage the gearcase.

Examine the drained gearcase lubricant for metal particles. A small amount of metal particles indicates normal gear wear. An excessive amount of metal filings or larger particles (chips) may indicate abnormal gear wear and should be checked by an authorized dealer.

Draining the Gearcase

1. Place the outboard in a vertical operating position.
2. Place the drain pan below the outboard.
3. Remove the fill/drain plug and vent plug and drain the lubricant.



Gearcase Lubricant Capacity

Gearcase lubricant capacity is approximately 320 ml (10.8 fl oz).

Gearcase Lubricant Recommendation


Mercury or Quicksilver Premium or High-Performance Gear Lubricant.

Checking Lubricant Level and Refilling Gearcase

1. Place the outboard in a vertical operating position.
2. Remove the vent plug from the vent hole.


MAINTENANCE

3. Place the lubricant tube into the fill hole and add lubricant until it appears at the vent hole.



IMPORTANT: Replace the sealing washers if damaged.

4. Stop adding lubricant. Install the vent plug and sealing washer before removing the lubricant tube.
5. Remove lubricant tube and install cleaned fill/drain plug and sealing washer.



Lubrication Points


1. Lubricate the following with 2-4-C with PTFE or Extreme Grease.

Description	Where Used	Part No.
Extreme Grease	Swivel bracket, transom clamp screws, tilt tube, throttle and shift cables, steering cable grease fitting	8M0190472
2-4-C with PTFE	Swivel bracket, transom clamp screws, tilt tube, throttle and shift cables, steering cable grease fitting	92-802859A 1

- Swivel bracket - Lubricate via the grease fitting.
- Transom clamp screws - Lubricate the threads.


MAINTENANCE

- Tilt tube - Lubricate via the grease fittings.



- a** - Tilt tube grease fitting
- b** - Swivel bracket grease fitting
- c** - Transom clamp screws

- **Tiller handle models:** Lubricate the throttle and shift cable moving components, pivot locations, and shift detent.




⚠ WARNING

Incorrect cable lubrication can cause hydraulic lock, leading to serious injury or death from loss of boat control. Completely retract the end of the steering cable before applying lubricant.


MAINTENANCE

- Steering cable grease fitting (if equipped) - Rotate the steering wheel to fully retract the steering cable end into the outboard tilt tube. Lubricate through the grease fitting.



- a - Steering cable grease fitting
- b - Steering cable end

- Lubricate the steering link rod pivot points with lightweight oil.




- a - Steering link rod pivot points

- Lubricate the propeller shaft with Extreme Grease or 2-4-C with PTFE.

Description	Where Used	Part No.
Extreme Grease	Propeller shaft	8M0190472
2-4-C with PTFE	Propeller shaft	92-802859A 1

- Refer to **Propeller Replacement** for removal and installation of the propeller.
- Apply lubricant to the entire propeller shaft to prevent the propeller hub from corroding to the shaft.




MAINTENANCE

Propeller Replacement


⚠ WARNING

Rotating propellers can cause serious injury or death. Never operate the boat out of the water with a propeller installed. Before installing or removing a propeller, place the drive unit in neutral and activate the lanyard stop switch to prevent the engine from starting. Place a block of wood between the propeller blade and the anti-ventilation plate.

1. Remove the spark plug lead to prevent engine from starting.



2. Move the gear shift lever into neutral (N).




3. Straighten and remove the cotter pin.
4. Place a block of wood between the gearcase and propeller to hold the propeller and remove the propeller nut.
5. Pull the propeller straight off the shaft. If the propeller is seized to the shaft and cannot be removed, have the propeller removed by an authorized dealer.

MAINTENANCE


IMPORTANT: To prevent the propeller hub from corroding and seizing to the propeller shaft (especially in saltwater), always apply the recommended lubricant to the entire propeller shaft at the recommended maintenance intervals and also each time the propeller is removed.

6. Apply Extreme Grease or 2-4-C with PTFE to the propeller shaft.



Description	Where Used	Part No.
Extreme Grease	Propeller shaft	8M0190472
2-4-C with PTFE	Propeller shaft	92-802859A 1

7. Install the front thrust washer, propeller, rear thrust washer, and propeller nut onto the shaft.
8. Place a block of wood between the gearcase and propeller to prevent rotation and tighten the propeller nut. Secure the propeller nut to the shaft with the cotter pin.




MAINTENANCE

Spark Plug Inspection and Replacement


⚠ WARNING

Damaged spark plug boots may emit sparks that can ignite fuel vapors under the engine cowl, resulting in serious injury or death from a fire or explosion. To avoid damaging the spark plug boots, do not use any sharp object or metal tool to remove the spark plug boots.


1. Remove the spark plug boot. Twist the rubber boot slightly and pull off.



2. Remove the spark plug to inspect. Replace spark plug if electrode is worn or the insulator is rough, cracked, broken, blistered, or fouled.



3. Set the spark plug gap to specification.



Spark Plug

Spark plug gap

0.9 mm (0.035 in.)

4. Before installing spark plug, clean off any dirt on the spark plug seat. Install plug finger-tight, and then tighten 1/4 turn or torque to specifications.


Description	Nm	lb-in.	lb-ft
Spark plug	27	-	20

MAINTENANCE

Timing Belt Inspection (Dealer Service Item)

Inspect the timing belt and have it replaced by an authorized dealer if any of the following conditions are found.

- Cracks in the back of the belt or in the base of the belt teeth.
- Excessive wear at the roots of the cogs.
- Rubber portion swollen by oil.
- Belt surfaces roughened.
- Signs of wear on edges or outer surfaces of belt.



MAINTENANCE

Notes:

STORAGE

Storage Preparation

The major consideration in preparing an outboard for storage is to protect it from rust, corrosion, and damage caused by the freezing of trapped water.

The following storage procedures should be used to prepare an outboard for out of season storage or prolonged storage (90 days or longer).

Protecting the Fuel System

NOTICE

Without sufficient cooling water, the engine, the water pump, and other components will overheat and suffer damage. Provide a sufficient supply of water to the water inlets during operation.


IMPORTANT: Gasoline containing alcohol (ethanol or methanol) can cause a formation of acid during storage and can damage the fuel system. If the gasoline being used contains alcohol, drain as much of the remaining gasoline as possible from the fuel tank, remote fuel line, and engine fuel system.

Fill the fuel tank and engine fuel system with treated (stabilized) fuel to help prevent formation of varnish and gum. Proceed with the following instructions.

- Portable fuel tank - Pour the required amount of Quickstor Fuel Stabilizer (follow instructions on container) into the fuel tank. Tip the fuel tank back and forth to mix the stabilizer with the fuel.
- Permanently installed fuel tank - Pour the required amount of Quickstor Fuel Stabilizer (follow instructions on container) into a separate container and mix it with approximately 1 liter (1 U.S. quart) of gasoline. Pour this mixture into fuel tank.

Description	Where Used	Part No.
Quickstor Fuel Stabilizer	Fuel tank	92-8M0047932

- Place the outboard in water or connect a flushing attachment for circulating cooling water. Run the engine for ten minutes to fill the engine fuel system.

Flushing Device	91-44357Q 2
	Attaches to the water intakes; provides a freshwater connection when flushing the cooling system or operating the engine.

Protecting External Outboard Components

- Lubricate all outboard components listed in **Maintenance - Inspection and Maintenance Schedule**.

STORAGE

- Touch up any paint nicks. See an authorized dealer for touch-up paint.
- Spray Quicksilver or Mercury Precision Lubricants Corrosion Guard on external metal surfaces (except corrosion control anodes).

Description	Where Used	Part No.
Corrosion Guard	External metal surfaces	92-802878 55

Protecting Internal Engine Components

- Remove the spark plugs and add approximately 30 ml (1 oz) of engine oil or inject a five second spray of storage seal inside of each cylinder.
- Rotate the flywheel manually several times to distribute the oil in the cylinders. Install spark plugs.
- Change the engine oil.

Gearcase


- Drain and refill the gearcase lubricant. Refer to **Gearcase Lubrication**.

Positioning Outboard for Storage

NOTICE

Storing the outboard in a tilted position can damage the outboard. Water trapped in the cooling passages or rain water collected in the propeller exhaust outlet in the gearcase can freeze. Store the outboard in the full down position.

- To prevent problems which can be caused by oil entering the cylinders from the sump, only store the outboard in one of the three positions shown.




- a - Upright position
- b - Tiller handle down
- c - Front side down

39056

STORAGE

- Never carry, store, or transport the outboard in the two positions shown. Engine damage could result from oil draining out of the crankcase.



Battery Storage

- Follow the battery manufacturer's instructions for storage and charging.
- Remove the battery from the boat and check the charge. Charge if necessary.
- Store the battery in a cool, dry place.
- Periodically check the battery voltage during storage. Charge if necessary.

STORAGE


Notes:

TROUBLESHOOTING

Fuse Replacement

Location of Fuses

The engine fuses are located at the port-front corner of the engine.




Fuse Identification and Replacement

IMPORTANT: An ATC fuse has the fuse element enclosed or sealed inside the plastic housing. This type of fuse must be used for marine applications. Marine applications are exposed to environments that may have the potential to accumulate explosive vapors. ATO fuses have exposed elements and should never be used in marine applications.

NOTE: Both fuse housings have a space for a spare fuse. Always carry spare fuses.


The voltage regulator circuit and the electric starting circuit are protected from overload by 20-amp and 15-amp fuses, respectively. If a fuse opens, try to locate and correct the cause of the overload. If the cause is not found, the fuse may open again.



- a** - Fuse holders with covers installed
- b** - Electric starting circuit - 15-amp fuse
- c** - Spare 15-amp fuse
- d** - Voltage regulator circuit - 20-amp fuse
- e** - Spare 20-amp fuse

TROUBLESHOOTING

Remove the fuse and examine the silver colored band inside the fuse. If the band is broken, replace the fuse. Replace the fuse with a new fuse of the same rating.



Starter Motor Will Not Crank the Engine (Electric Start Models)

Possible Causes

- Blown 15-amp fuse in the starting circuit. Refer to **Maintenance** section.

NOTE: Reverse battery connection will blow the 15-amp fuse.

- Outboard is not shifted to neutral position.
- Weak battery or battery connections are loose or corroded.
- Ignition key switch/start button failure.
- Wiring or electrical connection faulty.
- Starter motor or starter solenoid failure.

Engine Will Not Start

Symptom

The engine cranks, but will not start.

Possible Causes

- Incorrect starting procedure. Refer to **Operation** section.
- Old or contaminated gasoline.
- Engine flooded. Refer to **Operation** section.
- Fuel is not reaching the engine.
 - Fuel tank is empty.
 - Fuel tank vent not open or restricted.
 - Fuel line is disconnected or kinked.
 - Primer bulb not squeezed.
 - Primer bulb check valve is faulty.
 - Fuel filter is obstructed. Refer to **Maintenance** section.
 - Fuel pump failure.
 - Fuel tank filter obstructed.
- Electronic fuel injection system component failure.
- Ignition system component failure.

TROUBLESHOOTING

- Spark plugs fouled or defective. Refer to **Maintenance** section.

Engine Runs Erratically

Possible Causes

- Low oil pressure. Check the oil level.
- Spark plugs fouled or defective. Refer to **Maintenance** section.
- Incorrect setup and adjustments.
- Fuel is being restricted to the engine.
 - Engine fuel filter is obstructed. Refer to **Maintenance** section.
 - Fuel tank filter obstructed.
 - Stuck anti-siphon valve located on permanently built in type fuel tanks.
 - Fuel line is kinked or pinched.
- Fuel pump failure.
- Ignition system component failure.

Performance Loss

Possible Causes

- Low oil pressure. Check the oil level.
- Warning system activated.
- Throttle not fully open.
- Damaged or improper size propeller.
- Incorrect throttle linkage setup.
- Boat overloaded or load improperly distributed.
- Excessive water in bilge.
- Boat bottom is dirty or damaged.

Battery Will Not Hold Charge

Possible Causes

- Open fuse.
- Battery connections are loose or corroded.
- Worn out or inefficient battery.
- Excessive use of electrical accessories.
- Defective rectifier, stator, or voltage regulator.

TROUBLESHOOTING

Submerged Outboard

A submerged outboard will require service within a few hours by an authorized dealer once the outboard is recovered from the water. This immediate attention by a servicing dealer is necessary once the engine is exposed to the atmosphere to minimize internal corrosion damage to the engine.

OWNER SERVICE ASSISTANCE

Identification Records

The serial numbers are the manufacturer's keys to numerous engineering details that apply to a specific Mercury Marine power package. When contacting Mercury Marine about service, **always specify model and serial numbers.**

Please record the following applicable information:

Outboard		
Engine Model and Horsepower		
Engine Serial Number		
Gear Ratio		
Propeller Number	Pitch	Diameter
Watercraft Identification Number (WIN) or Hull Identification Number (HIN)		Purchase Date
Boat Manufacturer	Boat Model	Length
Exhaust Gas Emissions Certification Number (Europe Only)		

Service Assistance

Local Repair Service

If your Mercury-outboard-powered boat needs service, take it to a Mercury Marine Authorized Dealer. Only authorized dealers specialize in Mercury products and have factory-trained mechanics, special tools and equipment, and genuine Quicksilver parts and accessories to properly service your engine.

NOTE: *Quicksilver parts and accessories are engineered and built by Mercury Marine specifically for your power package.*

Service Away From Home

If you are away from home and the need for service arises, contact the nearest authorized dealer. If, for any reason, you cannot obtain service, contact the nearest Regional Service Center. Outside the United States and Canada, contact the nearest Marine Power International Service Center.

Stolen Power Package

If your power package is stolen, immediately advise the local authorities and Mercury Marine of the model and serial numbers and to whom the recovery is to be reported. This information is maintained in a database at Mercury Marine to aid authorities and dealers in the recovery of stolen power packages.

OWNER SERVICE ASSISTANCE

Attention Required After Submersion

1. Before recovery, contact a Mercury Marine Authorized Dealer.
2. After recovery, immediate service by a Mercury Marine Authorized Dealer is required to reduce the possibility of serious engine damage.

Replacement Service Parts

⚠ WARNING

Avoid fire or explosion hazard. Electrical, ignition, and fuel system components on Mercury Marine products comply with federal and international standards to minimize risk of fire or explosion. Do not use replacement electrical or fuel system components that do not comply with these standards. When servicing the electrical and fuel systems, properly install and tighten all components.

Marine engines are expected to operate at or near full throttle for most of their lives. They are also expected to operate in both fresh and saltwater environments. These conditions require numerous special parts.

Parts and Accessories Inquiries

Direct any inquiries concerning genuine Mercury Precision Parts® or Quicksilver Marine Parts and Accessories® to a local authorized dealer. Dealers have the proper systems to order parts and accessories, if they are not in stock.

Engine model and **serial number** are required to order correct parts.

Resolving a Problem

Satisfaction with your Mercury Marine product is important to your dealer and to us. If you ever have a problem, question, or concern about your power package, contact your dealer or any Mercury Marine Authorized Dealer. If you need additional assistance:

1. Talk with the dealership's sales manager or service manager.
2. If your question, concern, or problem cannot be resolved by your dealership, please contact the Mercury Marine Service Office for assistance. Mercury Marine will work with you and your dealership to resolve all problems.

The following information will be needed by the Customer Service:

- Your name and address
- Your daytime telephone number
- The model and serial numbers of your power package
- The name and address of your dealership
- The nature of the problem

OWNER SERVICE ASSISTANCE

Contact Information for Mercury Marine Customer Service

For assistance, call, fax, or write to the geographic office in your area. Please include your daytime telephone number with mail and fax correspondence.

United States, Canada		
Telephone	English +1 920 929 5040 Français +1 905 636 4751	Mercury Marine W6250 Pioneer Road P.O. Box 1939 Fond du Lac, WI 54936-1939
Fax	English +1 920 929 5893 Français +1 905 636 1704	
Website	www.mercurymarine.com	

Australia, Pacific		
Telephone	+61 3 9791 5822	Brunswick Asia Pacific Group 41-71 Bessemer Drive Dandenong South, Victoria 3175 Australia
Fax	+61 3 9706 7228	

Europe, Middle East, Africa		
Telephone	+32 87 32 32 11	Brunswick Marine in EMEA, LLC Avenue Mercury 8 B-4800 Verviers, Belgium
Email	BME.service@mercmarine.com	

Mexico, Central America, South America, Caribbean		
Telephone	+1 954 744 3500	Mercury Marine 11650 Interchange Circle North Miramar, FL 33025 U.S.A.
Fax	+1 954 744 3535	

Asia, Singapore, Japan		
Telephone	+65 68058100	Mercury Marine Singapore Pte Ltd 11 Changi South Street 3, #01-02 Singapore, 486122
Fax	+65 68058138	

Ordering Literature

Before ordering literature, have the following information about your power package available:

Model		Serial Number	
Horsepower		Year	

United States and Canada

For additional literature for your Mercury Marine power package, contact your nearest Mercury Marine dealer or contact:

OWNER SERVICE ASSISTANCE

Mercury Marine		
Telephone	Fax	Mail
(920) 929-5110	(920) 929-4894	Mercury Marine Attn: Publications Department P.O. Box 1939 Fond du Lac, WI 54936-1939

Outside the United States and Canada

Contact your nearest Mercury Marine authorized service center to order additional literature that is available for your particular power package.

Submit the following order form with payment to:	Mercury Marine Attn: Publications Department W6250 Pioneer Road P.O. Box 1939 Fond du Lac, WI 54936-1939
--	--

Ship To: (Copy this form and print or type—This is your shipping label)	
Name	
Address	
City, State, Province	
ZIP or postal code	
Country	

Quantity	Item	Stock Number	Price	Total
			.	.
			.	.
			.	.
			.	.
			.	.
Total Due				.

